# Chapter 1.

**Getting Started** 

**Turning the Computer On and Off** 

Turning the computer on

Turning the computer off

48

48

49


	_			
	Product Features	2		
	Before You Start	3		
	Contents			
	Safety Precautions	8		
	Proper Posture During Computer Use	22		
	Important Safety Information	2		
	Replacement Parts and Accessories			
	Regulatory Compliance Statements	29		
	WEEE SYMBOL INFORMATION	4		
	Overview	42		
	Front View	42		
	Status Indicators	43		
	Right View	44		
	Left View	4		
	Back View	46		
	Bottom View	4		

### **Product Features**



### **High-Performance Notebook Computer**

- Intel Core™2 Duo Processor, Pentium, Celeron Processor and DDR II Memory (Optional)
- Wireless LAN (Optional), Bluetooth (Optional)



### **Supports Various Multimedia Functions**

- A video chatting/conference function adopting the camera module (Optional)
- An HDMI port that enables viewing a full HD picture on the TV



### **Easy-to-Use and Convenient Functions**

- Various Hot Key Functions
- Multi-Card Slot
- Luxurious, Ergonomic Design



Optional items may be changed or may not be provided depending on the computer model.

### **Before You Start**

Before reading the User Guide, first check the following information.

#### **User Guide Information**

This product is supplied with an Installation Guide, and a User Guide.

You can even more easily and conveniently use the computer by using any of the guides depending on your needs.

#### Installation Guide

This guide is provided so that you can conveniently refer to this guide when using the computer for the first time after purchasing it.

This document includes the computer components and the connection procedures.

### User Guide Guide



You are currently reading the User Guide. To open the file at any time, double-click the icon on the Desktop. Alternatively, select Start > All Programs > Samsung > User Guide > User Guide.

This document includes the computer functions, how to use the functions, and how to use the programs.

### **Utilizing the User Guide**

- **1** Be sure to read the **Safety Precautions** before using the computer.
- 2 Refer to the separately supplied Installation Guide when installing your computer.
- Refer to the **User Guide** for the procedures to use the computer.
- 4 Using the Index of the User Guide, you can easily find any information you are looking for.
- **1** Using the **Glossary** of the User Guide, you can easily find meanings for technical terms.
- **1** If a problem occurs, refer to the **Q & A** included in the User Guide.



- Optional items, some devices and software referred to in the User Guide may not be provided and/or changed by upgrade.
  - Note that the computer environment referred in the User Guide may not be the same as your own environment.
- Images used in this User Guide may differ from actual product.
- This guide decribes procedures for using both the mouse and the touchpad.
- The illustrations provided in this guide assume that your operating system is Windows Vista. These illustrations are subject to change.
- The User guide supplied with this computer may vary depending on your model.

### **Safety Precaution Notations**

Icon	Notation	Description
	Warning	Failing to follow instructions marked with this symbol, may cause personal injury and or fatality.
$\triangle$	Caution	Failing to follow instructions marked with this symbol, may cause slight injury to yourself or damage your property.

### **Text Notations**

Icon	Notation	Description		
	Before You Start	Content included in this section includes information required before using a function.		
!	Caution	Content included in this section includes information required about the function.		
	Note	Content included in this section includes helpful information to use the function.		
	xx	This notation represents the page number you can refer to for information about related functions or as a reference.		
Start > All Programs > Samsung > User Guide > User Guide		This represents a menu path to run a program.  Click the Start button and then select All Programs > Samsung > User Guide > User Guide in this order from the menu.		

### Copyright

#### © 2009 Samsung Electronics Co., Ltd.

Samsung Electronics Co., Ltd. owns the copyright of this manual.

No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, without the consent of Samsung Electronics Co., Ltd.

The information in this document is subject to change without notice due to improving the performance of the product.

Samsung Electronics shall not be liable for any data loss. Please take care to avoid losing any important data and backup your data to prevent any such data loss.

### **Precautions for Operating System Support**

The operating system (OS) installed on this product is the latest version of Windows Vista.

Other operating systems (Windows 98, Windows ME, Windows 2000, Windows 2003 server, UNIX and LINUX, other Windows Vista versions, etc.) other than the operating system already installed on this computer are not supported.

If a problem occurs because of the installation of another operating system, the company will not provide technical support, a replacement or refund, and if our service engineer visits you due to this problem, a service charge will be applied.

In addition, installing a program that does not support Windows Vista, may cause the program to not work properly. In this case, ask the corresponding software manufacturer about the problem. If you request our services to resolve a problem caused by incompatible software, a service charge will be applied.

### **About the Product Capacity Representation Standard**

### **About HDD Capacity Representation**

The capacity of the storage device (HDD, SSD) of the manufacturer is calculated assuming that 1KB=1,000 Bytes.

However, the operating system (Windows) calculates the storage device capacity assuming that 1KB=1,024 Bytes, and therefore the capacity representation of the HDD in Windows is smaller than the actual capacity due to the difference in capacity calculation.

(E.g. For a 80GB HDD, Windows represents the capacity as 74.5GB, 80x1,000x1,000x1,000 byte/ (1,024x1,024x1,024)byte = 74.505GB)

In addition, the capacity representation in Windows may be even smaller because some programs such as Recovery Solution may reside in a hidden area of the HDD.

#### **About Memory Capacity Representation**

The memory capacity reported in Windows is less than the actual capacity of memory.

This is because BIOS or a video adapter uses a portion of memory or claims it for further use.

(E.g. For 1GB(=1,024MB) memory installed, Windows may report the capacity as 1,022MB or less)

# Contents

		Windows Wats Committee	75	Outtier - Deat Beautier	400
Chapter 1. Getting Started		Windows Vista Screen Layout Desktop	<b>75</b> 75	Setting a Boot Password	129
Product Features	2	Start Menu	77	Changing the Boot Priority	131
Before You Start	3	Sidebar / Gadget	79	Upgrading Memory	132
		Window	82	Battery	134
Contents	7	Control Panel	85	Installing/Removing the Battery	134
Safety Precautions	8	Opening the Control Panel	85	Charging the Battery	135
Proper Posture During Computer Use	22	User Accounts	87	Measuring	136
Important Safety Information	25	Changing the screen resolution		the Remaining Battery Charge Extending the Battery Usage Time	137
Replacement Parts and Accessories	27	and the color	89	, ,	141
Regulatory Compliance Statements	29	Configuring		Using the Security Lock Port	141
WEEE SYMBOL INFORMATION	41	the Start Menu Power Button	90		
Overview	42	Phishing Filter	92	Chapter 7. Windows Media Cen	tor
Front View	42	User control function	94	Chapter 7. Williams Media Cen	ter
Status Indicators	43	Windows Mobile Center	96	About Package Contents	
Right View	44			and the Program Guide	143
Left View	45	Observation 4. Hadron the Nickers de		Connecting	
Back View	46	<b>Chapter 4. Using the Network</b>		and Setting Up Media Center	144
Bottom View	47	Wired Network	98	Connecting Devices	144
Turning the Computer On and Off	48			Media Center Setup	145
Turning the computer on	48	Wireless Network	<b>101</b> 102	Using Media Center	147
Turning the computer off	49	Connecting to a Wireless LAN	102	Start Screen Layout	147
		Using the Easy Network Manager	400	Pictures + Videos	148
		(Optional)	<b>103</b> 103	Music	152
Chapter 2. Using the Computer		Network Settings Using in Another Location	103	TV + Movies	155
Kaybaard	51	Diagnosing the Network Status	105		
Keyboard		Connecting with a Modem (Optional)	107		
Touchpad	53	` . ,	107	Chapter 8. Appendix	
CD Drive (ODD, Optional)	56	Bluetooth (Optional) Bluetooth Function	108		
Inserting and Ejecting a CD	56	Using Bluetooth	100	Reinstalling Windows Vista (Optional)	160
Multi Card Slot	58	Osing Bidetooth	109	Using Samsung Recovery Solution	
ExpressCard Slot (Optional)	61			(Optional)	164
Connecting a monitor / TV	62	<b>Chapter 5. Using Applications</b>		Samsung Recovery Solution Function	
Connecting to the Monitor / TV	62	Chapter 5. Coming Applications		Using Samsung Recovery Solution	166
Viewing Through a Monitor / TV	64	Introducing Programs	114	Q & A	171
Using Dual View	68	Samsung Update Plus (Optional)	117	Display Related	171
Adjusting the Volume	70	Samsung Magic Doctor (Optional)	119	Sound Related	173 174
		Reinstalling Software (Optional)	121	Modem Related Wired Network (LAN) Related	174
		Remstaning Software (Optional)	121	Wireless Network (WLAN) Related	177
Chapter 3. Using Microsoft				Game and Program Related	181
Windows Vista		Chapter 6. Settings and Upgrad	10	Bluetooth	182
About Microsoft Windows Vist-	70	Onapter o. Settings and Opgrace		Blu-Ray (Optional)	184
About Microsoft Windows Vista	73 72	LCD Brightness Control	124	Other	185
Welcome Center	73 74	BIOS Setup	125	Product Specifications	186
Help and Support	74	Entering the BIOS Setup	125	Glossary	198
		The BIOS Setup Screen	127	·	201
		=		Index	4U I

# Safety Precautions

For your security and to prevent damage, please read the following safety instructions carefully. Since this is commonly applied to Samsung Computers, some pictures may differ from actual products.



Failing to follow instructions marked with this symbol may cause personal injury and even fatality.

### Installation Related




Do not install the product in places exposed to humidity such as a bathrooms.

There is a danger of electric shock. Use the product within the operating conditions specified in the Manufacturers User Guide.



Keep the plastic bags out of the reach of children.

There is a danger of suffocation.



Keep a distance of 15cm or more between the computer and the wall and do not place any objects between them.

This may increase the internal temperature of the computer and may cause an injury.



Do not install the computer on a slant or a place prone to vibrations, or avoid using the computer in that location for a long time.

This increases the risk that a malfunction or damage to the product will occur.



Avoid exposing any part of your body to the heat from the computer vent or AC adapter for a long time when the computer is on.

Exposing a part of your body close to the heat from the vent or AC adapter for long periods of time may cause a burn.



Avoid blocking the vent at the bottom or side of the computer when using it on a bed or cushion.

If the vent is blocked, there is a danger of damaging the computer or overheating the inside of the computer.




### **Power Related**

The power plug and wall outlet figures may differ depending on the country specifications and the product model.



Do not touch the main plug or power cord with wet hands.

There is a danger of electric shock.




If the power cord or power outlet makes a noise, disconnect the power cord from the wall outlet and contact a service center.

There is a danger of electric shock or fire hazard.




Plug the power cord firmly into the power outlet and AC adapter.

Failing to do so may cause fire hazard.



Do not exceed the standard capacity (voltage/current) of a multiplug or power outlet extension when using it for the product.

There is a danger of electric shock or fire hazard.



Do not use a damaged or loose main plug or power cord or power outlet.


There is a danger of electric shock or fire hazard.



Do not unplug the power cord out by pulling the cable only.

If the cord is damaged, it may cause electric shock.





Do not bend the power cord excessively or do not place a heavy object over the power cord. It is especially important to keep the power cord out of reach of infants and pets.

If the cord is damaged, it may cause electric shock or fire.



If water or another substance enters the power input jack, AC adapter or the computer, disconnect the power cord and contact the service center.

Damage to the device within the computer may cause electric shock or fire hazard.

# AC Adapter Usage Precautions




Do not place heavy objects or step onto the power cord or AC adapter to avoid damaging the power cord or AC adapter.

If the cord is damaged, there is a danger of electric shock or fire.

Use only the AC adapter supplied with the product.

Using another adapter may cause the screen to flicker.





# Connect the power cord to the AC adapter firmly.

Otherwise, there is a danger of fire due to an incomplete contact.

### **Battery Usage Related**



Keep the battery out of the reach of infants and pets, as they could put the battery into their mouths.

There is a danger of electric shock or choking.



Use an authorized battery and AC adapter only.

Please use an authorized battery and adapter approved by Samsung Electronics.

Unauthorized batteries and adapters may not meet the proper safety requirements and may cause problems or malfunctions and result in an explosion or fire.





Do not use the computer in a badly ventilated location such as on bedding, on a pillow or cushion, etc, and do not use it in a location such as room with floor heating as it may cause the computer to overheat.

Take care that the computer vents (on the side or the bottom) are not blocked especially in these environments. If the vents are blocked, the computer may overheat and it may cause a computer problem, or even an explosion.



Do not use the computer in a humid location such as a bathroom or sauna.

Please use the computer within the recommended temperature and humidity range (10~35°C, 20~80% RH).



Do not close the LCD panel and put the computer into your bag to move it when it is still turned on.

If you put the computer into your bag without turning it off, the computer may overheat and there is a danger of fire. Shut the computer down properly before moving it.



Never heat the battery or put the battery into a fire. Do not put or use the battery in a hot location such as a sauna, inside a vehicle exposed to the heat, and so on.

There is a danger of an explosion or fire.





Take care not to allow metal objects such as a key or clip to touch the battery terminal (metal parts).

If a metal object touches the battery terminals, it may cause excessive current flow and it may damage the battery, or result in a fire.



If liquid leaks out of the battery or there is a funny smell coming from the battery, remove the battery from the computer and contact a service center.

There is a danger of an explosion or fire.



Please charge the battery fully before using the computer for the first time.



To use the computer safely, replace a dead battery with a new, authorized battery.




### **Usage Related**



Disconnect all cables connected to the computer before cleaning it. If you are cleaning a notebook computer, remove the battery.

There is a danger of electric shock or damage to the product.



Do not place any container filled with water or chemicals over or near the computer.

If water or chemicals enter the computer, this may cause fire or electric shock.



Avoid direct sunlight when the computer is in an air-tight location such as inside a vehicle.

There is a danger of a fire hazard. The computer may overheat and also present opportunity to thieves.



Do not connect a phone line connected to a digital phone to the modem.

There is a danger of a electric shock, fire or damage to the product.




If the computer is broken or dropped, disconnect the power cord and contact a service center for a safety check.

Using a broken computer may cause electric shock or fire hazard.



### **Upgrade Related**



Never disassemble the power supply or AC adapter.

There is a danger of electric shock.



Use only authorized parts (multiplug, battery and memory) and never disassemble parts.

There is a danger of damaging the product, electric shock or fire hazard.



Shut down the computer and disconnect all cables before disassembling the computer. If there is a modem, disconnect the phone line. If you are disassembling notebook computer, make sure to remove the battery.

Failing to do so, may cause electric shock.



When removing the RTC (Real Time Clock) battery, keep it out of the reach of children as they could touch and/or swallow it.

There is a danger of choking. If a child has swallowed it, contact a doctor immediately.



### **Custody and Movement Related**



Follow the instructions for the relevant location (e.g. airplane, hospital, etc.) when using a wireless communication device (wireless LAN, Bluetooth, etc.).



When carrying the notebook computer with other items, such as the adapter, mouse, books etc, take care not to press anything against the notebook computer.

If a heavy object is pressed against the notebook computer, a white spot or stain may appear on the LCD. Therefore, take care not to apply any pressure to the notebook.

In this case, place the notebook computer in a separate compartment away from the other objects.

### **A** Caution

Failing to follow instructions marked with this symbol may cause slight injury or damage to the product.

#### Installation Related

Do not block the ports (holes), vents, etc. of the product and do not insert objects.

Damage to a component within the computer may cause electric shock or fire.

When using the computer with it lying on its side, place it so that the vents face upwards.

Failing to do so, may cause the internal temperature of the computer to rise and the computer to malfunction or halt.

### Do not place a heavy object over the product.

This may cause a problem with the computer. In addition, the object may fall and cause injury, or damage the computer.

### **Battery Usage Related**

### Dispose of worn-out batteries properly.

- There is a danger of fire or explosion.
- The battery disposal method may differ depending on your country and region. Dispose of the used battery in an appropriate way.

### Do not throw or disassemble the battery and do not put it into water.

This may cause an injury, fire or explosion.

### Use only a battery authorized by Samsung Electronics.

Failing to do so may cause an explosion.



Failing to follow instructions marked with this symbol may cause slight injury or damage to the product.

# Avoid contact with metal objects such as car keys or clips when keeping or carrying a battery.

Contact with a metal may cause excessive current and a high temperature and may damage the battery or cause a fire.

### Charge the battery according to the instructions in the manual.

Failing to do so, may cause an explosion or fire from damage to the product.

#### Do not heat the battery or expose it to heat (e.g. inside a vehicle during the summer).

There is a danger of explosion or fire.

### **Usage Related**

### Do not place a candle, light cigar, etc. over or on the product.

There is a danger of fire.

### Use a wall outlet or multi-plug with a grounding part.

Failing to do so may cause electric shock hazard.

# Make sure to have the product tested by a safety service engineer after repairing the product.

Authorized Samsung Repair Centers will carry out safety checks after a repair. Using a repaired product without testing it for safety may cause an electric shock or fire.

In case of lightning, immediately turn the system off, disconnect the power cord from the wall outlet and phone line from modem. Do not use a modem or phone.

There is a danger of electric shock or fire.

# Do not use your computer and AC-Adapter on your lap or soft surfaces.

If the computer temperature increases, there is a danger of burning yourself.

# Connect only permitted devices to the connectors or ports of the computer.

Failing to do so, may cause electric shock and fire.

# Close the LCD panel only after checking if the notebook computer is turned off.

The temperature may rise and it may cause overheating and deformation of the product.

### **A** Caution

Failing to follow instructions marked with this symbol may cause slight injury or damage to the product.

#### Do not press the Eject Button while the Floppy Disk/CD-ROM drive is in operation.

You might lose data and the disk might be suddenly ejected and could cause an injury.

# Take care not to drop the product while using it.

This may cause personal injury or loss of data.

# Do not touch the antenna with electricity facility such as the power outlet.

There is a danger of electric shock.

# When handling computer parts, follow the instructions on the manual supplied with the parts.

Failing to do so, may cause damage to the product.

If the computer emits smoke, or there is a burning smell, disconnect the power plug from the wall outlet and contact a service center. If your computer is a notebook computer, make sure to remove the battery.

There is a danger of fire.

### Do not use a damaged or modified CD/Floppy Disk.

There is a danger of damaging the product or personal injury.

### Do not insert your fingers into the PC Card Slot.

There is a danger of injury or electric shock.

# Use recommended computer cleansing solution when cleaning the product and only use the computer when it is completely dried.

Failing to do so may cause electric shock or fire.

Emergency disk eject method using paperclip should not be used while the disk is in motion. Make sure to use the emergency disk eject method only when the Optical Disk Drive is stopped.

There is a danger of injury.

# Do not place your face close to the Optical Disk Drive tray when it is operating.

There is a danger of injury due to an abrupt ejection.

### Check CDs for cracks and damage prior to use.

It may damage the disc and cause disorder of device and injury of user.

### **A** Caution

Failing to follow instructions marked with this symbol may cause slight injury or damage to the product.

### **Upgrade Related**

### Take care when touching the product or parts.

The device may be damaged or you may be injured.

### Take care not to throw or drop a computer part or device.

This may cause injury or damage to the product.

# Make sure to close the computer cover before connecting the power after a reassembly.

There is a danger of electric shock if your body touches an internal part.

### Use parts authorized by Samsung Electronics only.

Failing to do so, may cause fire or damage the product.

### Never disassemble or repair the product by yourself.

There is a danger of electric shock or fire.

# To connect a device that is not manufactured or authorized by Samsung Electronics, enquire at your service center before connecting the device.

There is a danger of damaging the product.

# **Custody and Movement Related**

# When moving the product, turn the power off and separate all connected cables first.

The product might be damaged or users may trip over the cables.

# For long periods of not using the notebook computer, discharge the battery and preserve as it is detached.

The battery will be preserved at its best condition.

## Do not operate or watch the computer while driving a vehicle.

There is a danger of a traffic accident. Please concentrate on driving.



Failing to follow instructions marked with this symbol may cause slight injury or damage to the product.

### **Cautions on Preventing Data Loss (Hard Disk Management)**

#### Take care not to damage the data on a hard disk drive.

- A hard disk drive is so sensitive to external impact that an external impact may cause loss of data on the surface of the disk.
- Take extra care, because moving the computer or an impact on the computer when it is turned on may damage the data of the hard disk drive.
- The company is not liable for any loss of any data caused by a customer's careless usage or bad environmental conditions.

#### Causes that may damage the data of a hard disk drive and the hard disk drive itself.

- The data may be lost when an external impact is applied to the disk while disassembling or assembling the computer.
- The data may be lost when the computer is turned off or reset by a power failure while the hard disk drive is operating.
- The data may be lost and irrecoverable due to a computer virus infection.
- The data may be lost if the power is turned off while running a program.
- Moving or causing an impact to the computer while the hard disk drive is operating, may cause files to be corrupted or bad sectors on the hard disk.

To prevent data loss due to damage to the hard disk drive, please backup your data frequently.

# Proper Posture During Computer Use

Maintaining a proper posture during computer use is very important to prevent physical harm.

The following instructions are about maintaining a proper posture during computer use developed through human engineering. Please read and follow them carefully when using the computer.

Otherwise, the probability of (RSI: Repetitive Strain Injury) from repeated operations may increase and serious physical harm may be caused.



- The instructions in this manual have been prepared so that they can be applied within the coverage of general users.
- If the user is not included in the coverage, the recommendation is to be applied according to the user's needs.

### **Proper Posture**

# Adjust the heights of desks and chairs appropriate to your height.

The heights are to be adjusted so that your arm forms a right angle when you place your hand over the keyboard while sitting down on a chair.

Adjust the height of chair so that your heel is comfortably placed on the floor.


- Do not use the computer while you are lying down, but only while you are sitting down.
- Do not use the computer on your lap. If the computer temperature increases, there is a danger of burning yourself.
- Work while keeping your wrist straight.
- Use a chair with a comfortable back.
- Keep the center of your leg weight not on the chair but on your feet when you are sitting on a chair.

- To use the computer while talking over the telephone, use a headset. Using the computer with the phone on your shoulder is bad for posture.
- Keep frequently used items within a comfortable work range (where you can reach them with your hands).



### **Eye Position**


Keep the monitor or LCD away from your eyes by at least 50cm.



- Adjust the height of the monitor and the LCD screen so that its top height is equal to or lower than your eyes.
- Avoid setting the monitor and LCD excessively bright.
- Keep the monitor and LCD screen clean.
- If you wear glasses, clean them before using the computer.
- When entering contents printed on a paper into the computer, use a static paper holder so that the height of the paper is almost equal to that of the monitor.

#### **Hand Position**

Keep your arm at a right angle as shown by the figure.



- Keep the line from your elbow to your hand straight.
- Do not place your palm over the keyboard while typing.
- Do not hold the mouse with excessive force.
- Do not press the keyboard, touchpad or mouse with excessive force.
- It is recommended connecting an external keyboard and mouse when using the computer for long periods of time.

# **Volume Control** (Headphones and Speakers)

#### Check your volume first to listen to music.



- Check if the volume is too loud before using headphones.
- It is not recommended using headphones for long periods of time.
- Any deviation from the equalizer default setting could cause hearing impairment.
- The default setting can be changed through software and driver updates without your intervention. Please check the equalizer default setting before first usage.

### **Use Time (Break Time)**

 Take a break for 10 minutes or more after a 50-minute period when working for more than one hour.

### Illumination

- Do not use the computer in dark locations. The illumination level for computer use must be as bright so for reading a book.
- Indirect illumination is recommended. Use a curtain to prevent reflection on the LCD screen.

### **Operation Condition**

- Do not use the computer in hot and humid locations.
- Use the computer within the allowed temperature and humidity range specified in the User Guide.

## Important Safety Information

### **Safety Instructions**

Your system is designed and tested to meet the latest standards for safety of information technology equipment. However, to ensure safe use of this product, it is important that the safety instructions marked on the product and in the documentation are followed.



Always follow these instructions to help guard against personal injury and damage to your system.

### **Setting Up your System**

- Read and follow all instructions marked on the product and in the documentation before you operate your system. Retain all safety and operating instructions for future use.
- Do not use this product near water or a heat source such as a radiator.
- Set up the system on a stable work surface.
- The product should be operated only with the type of power source indicated on the rating label.
- Ensure that the electrical outlet you are using to power your equipment is easily accessible in case of fire or short circuit.
- If your computer has a voltage selector switch, make sure that the switch is in the proper position for your area.

- Openings in the computer case are provided for ventilation. Do not block or cover these openings.
   Make sure you provide adequate space, at least 6 inches (15 cm), around the system for ventilation when you set up your work area. Never insert objects of any kind into the computer ventilation openings.
- Ensure that the fan vents on the bottom of the casing are clear at all times. Do not place the computer on a soft surface, doing so will block the bottom vents.
- If you use an extension cord with this system, make sure that the total power rating on the products plugged into the extension cord does not exceed the extension cord power rating.

### **Care During Use**

- Do not walk on the power cord or allow anything to rest on it.
- Do not spill anything on the system. The best way to avoid spills is to not eat or drink near your system.
- Some products have a replaceable CMOS battery on the system board. There is a danger of explosion if the CMOS battery is replaced incorrectly. Replace the battery with the same or equivalent type recommended by the manufacturer.
   Dispose of batteries according to the manufacturers instructions. If the CMOS battery requires replacement insure that a qualified technician performs the task.
- When the computer is turned off, a small amount of electrical current still flows through the computer.
   To avoid electrical shock, always unplug all power cables, remove the battery and modem cables from the wall outlets before cleaning the system.
- Unplug the system from the wall outlet and refer servicing to qualified personnel if:
  - The power cord or plug is damaged.
  - Liquid has been spilled into the system.
  - The system does not operate properly when the operating instructions are followed.
  - The system was dropped or the casing is damaged.
  - The system performance changes.

# The Instruction On Safety Operation of NotePC

- **1** When installing and operating devices please refer to safety requirements in the user guide.
- **2** Devices can be used only with the equipment specified in the technical specifications of the devices.
- If any smell of burning or smoke is detected from the computer the unit should be switched off and battery removed. The unit should be checked by a qualified technician before reuse.
- Service and repair of devices should be carried out by authorized service centers.
- **6** Do not allow your portable computer to operate with the base resting directly on exposed skin for extended periods of time. The surface temperature of the base will rise during normal operation (particularly when AC Power is present). Allowing sustained contact with exposed skin can cause discomfort or eventually a burn.

# Replacement Parts and Accessories

Use only replacement parts and accessories recommended by manufacturer.



To reduce the risk of fire, use only No. 26 AWG or larger telecommunications line cord.



Do not use this product in areas classified as hazardous. Such areas include patient care areas of medical and dental facilities, oxygen rich environments, or industrial areas.

### **Battery Disposal**



Do not put rechargeable batteries or products powered by non-removable rechargeable batteries in the garbage.

Contact the Samsung Helpline for information on how to dispose of batteries that you cannot use or recharge any longer.

Follow all local regulations when disposing of old batteries.



THERE IS A RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

### **Laser Safety**

All systems equipped with CD or DVD drives comply with the appropriate safety standards, including IEC 60825-1. The laser devices in these components are classified as "Class 1 Laser Products" under a US Department of Health and Human Services (DHHS) Radiation Performance Standard. Should the unit ever need servicing, contact an authorized service location.



#### Laser Safety Note:

Use of controls or adjustments or performance of procedures other than those specified in this manual may result in hazardous radiation exposure. To prevent exposure to laser beams, do not try to open the enclosure of a CD or DVD drive.

- Class 1M laser radiation when operating part is open.
  - Do not view directly with optical instruments.
- Class 3B invisible laser radiation when open.
   Avoid exposure to the beam.

# **Connect and Disconnect the AC adapter**

The socket-outlet shall be installed near the equipment and shall be easily accessible.

Do not unplug the power cord out by pulling the cable only.

### **Power Cord Requirements**

The power cord set (wall plug, cable and AC adapter plug) you received with your computer meets the requirements for use in the country where you purchased your equipment.

Power cord sets for use in other countries must meet the requirements of the country where you use the computer. For more information on power cord set requirements, contact your authorized dealer, reseller, or service provider.

### **General Requirements**

The requirements listed below are applicable to all countries:

- The length of the power cord set must be at least 6.00 feet (1.8m) and a maximum of 9.75 feet (3.0m).
- All power cord sets must be approved by an acceptable accredited agency responsible for evaluation in the country where the power cord set will be used.
- The power cord set must have a minimum current capacity of 7 A and a nominal voltage rating of 125 or 250 volts AC, as required by each country's power system.
- The appliance coupler must meet the mechanical configuration of an EN 60 320/IEC 320 Standard Sheet C7 connector, for mating with appliance inlet on the computer.

# Regulatory Compliance Statements

### **Wireless Guidance**

Low power, Radio LAN type devices (radio frequency (RF) wireless communication devices), operating in the 2.4GHz/5GHz Band, may be present (embedded) in your notebook system. The following section is a general overview of considerations while operating a wireless device.

Additional limitations, cautions, and concerns for specific countries are listed in the specific country sections (or country group sections). The wireless devices in your system are only qualified for use in the countries identified by the Radio Approval Marks on the system rating label. If the country you will be using the wireless device in, is not listed, please contact your local Radio Approval agency for requirements. Wireless devices are closely regulated and use may not be allowed.

The RF field strength of the wireless device or devices that may be embedded in your notebook are well below all international RF exposure limits as known at this time. Because the wireless devices (which may be embedded into your notebook) emit less energy than is allowed in radio frequency safety standards and recommendations, manufacturer believes these devices are safe for use. Regardless of the power levels, care should be taken to minimize human contact during normal operation.

As a general guideline, a separation of 20 cm (8 inches) between the wireless device and the body, for use of a wireless device near the body (this does not include extremities) is typical. This device should be used more than 20 cm (8 inches) from the body when wireless devices are on and transmitting.

This transmitter must not be collocated or operate in conjunction with any other antenna or transmitter except the installed Bluetooth transmitter.

Some circumstances require restrictions on wireless devices. Examples of common restrictions are listed on the next page:



- Radio frequency wireless communication can interfere with equipment on commercial aircraft. Current aviation regulations require wireless devices to be turned off while traveling in an airplane.
   802.11ABGN (also known as wireless Ethernet or Wifi) and Bluetooth communication devices are examples of devices that provide wireless communication.
- In environments where the risk of interference to other devices or services is harmful or perceived as harmful, the option to use a wireless device may be restricted or eliminated. Airports, Hospitals, and Oxygen or flammable gas laden atmospheres are limited examples where use of wireless devices may be restricted or eliminated. When in environments where you are uncertain of the sanction to use wireless devices, ask the applicable authority for authorization prior to use or turning on the wireless device.
- Every country has different restrictions on the use of wireless devices. Since your system is equipped with a wireless device, when traveling between countries with your system, check with the local Radio Approval authorities prior to any move or trip for any restrictions on the use of a wireless device in the destination country.
- If your system came equipped with an internal embedded wireless device, do not operate the wireless device unless all covers and shields are in place and the system is fully assembled.
- Wireless devices are not user serviceable. Do not modify them in any way. Modification to a wireless device will void the
  authorization to use it. Please contact manufacturer for service.
- Only use drivers approved for the country in which the device will be used. See the manufacturer System Restoration Kit, or contact manufacturer Technical Support for additional information.

### **United States of America**

# **USA and Canada Safety Requirements** and Notices

Do not touch or move antenna while the unit is transmitting or receiving.

Do not hold any component containing the radio such that the antenna is very close or touching any exposed parts of the body, especially the face or eyes, while transmitting.

Do not operate the radio or attempt to transmit data unless the antenna is connected; if not, the radio may be damaged.

#### Use in specific environments:

The use of wireless devices in hazardous locations is limited by the constraints posed by the safety directors of such environments.

The use of wireless devices on airplanes is governed by the Federal Aviation Administration (FAA).

The use of wireless devices in hospitals is restricted to the limits set forth by each hospital.



#### **Explosive Device Proximity Warning**

Do not operate a portable transmitter (such as a wireless network device) near unshielded blasting caps or in an explosive environment unless the device has been modified to be qualified for such use.



#### **Use On Aircraft Caution**

Regulations of the FCC and FAA prohibit airborne operation of radio-frequency wireless devices because their signals could interfere with critical aircraft instruments.

#### Other Wireless Devices

Safety Notices for Other Devices in the Wireless Network: Refer to the documentation supplied with wireless Ethernet adapters or other devices in the wireless network.



The Part 15 radio device operates on a noninterference basis with other devices operating at this frequency. Any changes or modification to said product not expressly approved by Intel could void the user's authority to operate this device.

### **Unintentional Emitter per FCC Part 15**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, it may cause harmful interference. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

If necessary, the user should consult the dealer or an experienced radio/television technician for additional suggestions. The user may find the following booklet helpful: "Something About Interference."

This is available at FCC local regional offices. Our company is not responsible for any radio or television interference caused by unauthorized modifications of this equipment or the substitution or attachment of connecting cables and equipment other than those specified by our company. The correction will be the responsibility of the user. Use only shielded data cables with this system.

### **Intentional emitter per FCC Part 15**

Low power, Radio LAN type devices (radio frequency (RF) wireless communication devices), operating in the 2.4GHz/5GHz Band, may be present (embedded) in your notebook system. This section is only applicable if these devices are present. Refer to the system label to verify the presence of wireless devices.

Wireless devices that may be in your system are only qualified for use in the United States of America if an FCC ID number is on the system label.

This device is restricted to indoor use due to its operation in the 5.15 to 5.25 GHz frequency range. FCC requires this product to be used indoors for the frequency range 5.15 to 5.25 GHz to reduce the potential for harmful interference to co-channel Mobile Satellite systems. High power radars are allocated as primary users of the 5.25 to 5.35 GHz and 5.65 to 5.85 GHz bands. These radar stations can cause interference with and /or damage this device.

The FCC has set a general guideline of 20 cm (8 inches) separation between the device and the body, for use of a wireless device near the body (this does not include extremities). This device should be used more than 20 cm (8 inches) from the body when wireless devices are on. The power output of the wireless device (or devices), which may be embedded in your notebook, is well below the RF exposure limits as set by the FCC.

This transmitter must not be collocated or operate in conjunction with any other antenna or transmitter except the installed Bluetooth transmitter.

Operation of this device is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation of the device.



Wireless devices are not user serviceable. Do not modify them in any way.

Modification to a wireless device will void the authorization to use it. Contact manufacturer for service.



#### FCC Statement for Wireless LAN use:

"While installing and operating this transmitter and antenna combination the radio frequency exposure limit of 1mW/cm2 may be exceeded at distances close to the antenna installed. Therefore, the user must maintain a minimum distance of 20cm from the antenna at all times.

This device can not be colocated with another transmitter and transmitting antenna."

# FCC Part 68 (If fitted with a modem device.)

This equipment compiles with part of the FCC rules. On the back of this equipment is a label that contains, among other information, the FCC registration number and ringer equivalence number (REN) for this equipment. If requested, this information must be provided to the telephone company.

This equipment uses the following USOC jacks: RJ11C

An FCC compliant telephone cord and modular plug is provided with this equipment. This equipment is designed to be connected to the telephone network or promises wiring using a compatible modular jack which is Part 68 compliant. See Installation Instructions for details.

The REN is used to determine the quantity of devices which may be connected to telephone line. Excessive RENs on the telephone line may result in the devices not ringing in response to an incoming call. In most, but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by total RENs, contact the local telephone company to determine the maximum REN for the calling area.

If the terminal equipment causes harm to the telephone network, the Telephone Company will notify you in advance that temporary discontinuance of service may be required. But if advance notice is not practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the operation of the equipment. If this happens, the telephone company will provide advanced notice in order for you to make necessary modifications to maintain uninterrupted service.

If trouble is experienced with this equipment (Modem) for repair or warranty information, please contact your local distributor. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

The user must use the accessories and cables supplied by the manufacturer to get optimum performance from the product.

No repairs may be done by the customer.

This equipment cannot be used on public coin phone service provided by the telephone company. Connection to party line service is subject to state tariffs.

The Telephone Consumer Protection Act of 1991 makes it unlawful for any person to use a computer or other electronic device, including fax machines, to send any message unless such message clearly contains in a margin at the top or bottom of each transmitted page or on the first page of the transmission, the date and time it is sent and an identification of the business or other entity, or other individual sending the message and the telephone number of the sending machine or such business, other entity, or individual. (The telephone number provided may not be any number for which charges exceed local or long-distance transmission charges.)

In order to program this information into your fax machine, refer to your communications software user manual.

### Canada

### **Unintentional Emitter per ICES-003**

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the radio interference regulations of Industry Canada.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limitesapplicables aux appareils numériques de Classe B prescrites dans le règlement sur le brouillage radioélectrique édicté par Industrie Canada.

### **Intentional Emitter per RSS 210**

Low power, Radio LAN type devices (radio frequency (RF) wireless communication devices), operating in the 2.4GHz/5GHz Band, may be present (embedded) in your notebook system. This section is only applicable if these devices are present. Refer to the system label to verify the presence of wireless devices.

Wireless devices that may be in your system are only qualified for use in Canada if an Industry Canada ID number is on the system label.

When using IEEE 802.11a wireless LAN, this product is restricted to indoor use due to its operation in the 5.15- to 5.25-GHz frequency range. Industry Canada requires this product to be used indoors for the frequency range of 5.15 GHz to 5.25 GHz to reduce the potential for harmful interference to co-channel mobile satellite systems. High power radar is allocated as the primary user of the 5.25-to 5.35-GHz and 5.65 to 5.85-GHz bands. These radar stations can cause interference with and/or damage to this device.

The maximum allowed antenna gain for use with this device is 6dBi in order to comply with the E.I.R.P limit for the 5.25- to 5.35 and 5.725 to 5.85 GHz frequency range in point-to-point operation.

As a general guideline, a separation of 20 cm (8 inches) between the wireless device and the body, for use of a wireless device near the body (this does not include extremities) is typical. This device should be used more than 20 cm (8 inches) from the body when wireless devices are on.

The power output of the wireless device (or devices), which may be embedded in your notebook, is well below the RF exposure limits as set by Industry Canada.

This transmitter must not be collocated or operate in conjunction with any other antenna or transmitter except the installed Bluetooth transmitter.

Operation of this device is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation of the device.



To prevent radio interference to licensed service, this device is intended to be operated indoors and away from windows to provide maximum shielding. Equipment (or its transmit antenna) that is installed outdoors is subject to licensing.



Wireless devices are not user serviceable. Do not modify them in any way. Modification to a wireless device will void the authorization to use it. Contact manufacturer for service.

# Telecommunications per DOC notice (for products fitted with an IC-compliant modem)

The Industry Canada label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operation, and safety requirements. The Department does not guarantee the equipment will operate to the users' satisfaction.

Before installing this equipment, users should make sure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. In some cases, the inside wiring associated with a single-line individual service may be extended by means of a certified connector assembly. The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should make sure, for their own protection, that the electrical ground connections of the power utility, telephone lines, and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.



To avoid electrical shock or equipment malfunction do not attempt to make electrical ground connections by yourself. Contact the appropriate inspection authority or an electrician, as appropriate.

The **Ringer Equivalence Number** (REN) assigned to each terminal device provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed 5.

#### **European Union**

# **European Union CE Marking and Compliance Notices**

Products intended for sale within the European Union are marked with the Conformité Européene (CE) Marking, which indicates compliance with the applicable Directives and European standards and amendments identified below. This equipment also carries the Class 2 identifier.

The following information is only applicable to systems labeled with the CE mark ( •

#### **European Directives**

This Information Technology Equipment has been tested and found to comply with the following European directives:

- EMC Directive 89/336/EEC with amending directives 92/31/EEC & 93/68/EEC as per
  - EN 55022 Class B
  - EN 61000-3-2
  - EN 61000-3-3
  - EN 55024
- Low Voltage Directive (Safety) 73/23/EEC as per EN 60950(A1/A2/A3/A4/A11)
- Radio and Telecom Terminal Equipment Directive 1999/5/EC as per
  - CTR21 (if fitted with a modem device)
  - EN 300 328 (if fitted with a 2.4 GHz band embedded wireless device)
  - EN 301 489-1 (if fitted with a 2.4 GHz band embedded wireless device)
  - EN 301 489-17 (if fitted with a 2.4 GHz band embedded wireless device)
  - EN 301 893 (if fitted with a 5 GHz band embedded wireless device)

#### **European Radio Approval Information**

(for products fitted with EU-approved radio devices)

This Product is a Notebook computer; low power, Radio LAN type devices (radio frequency (RF) wireless communication devices), operating in the 2.4GHz/5GHz band, may be present (embedded) in your notebook system which is intended for home or office use. This section is only applicable if these devices are present. Refer to the system label to verify the presence of wireless devices.

Wireless devices that may be in your system are only qualified for use in the European Union or associated areas if a CE mark **(** with a Notified Body Registration Number and the Alert Symbol is on the system label.

The power output of the wireless device or devices that may be embedded in you notebook is well below the RF exposure limits as set by the European Commission through the R&TTE directive.

The low band 5.15 - 5.35 GHz is for indoor use only.



See 802.11b and 802.11g restrictions for specific countries or regions within countries under the heading "European Economic Area Restrictions" below.

#### **Translated Statements of Compliance**

#### [English]

This product follows the provisions of the European Directive 1999/5/EC.

#### [Danish]

Dette produkt er i overensstemmelse med det europæiske direktiv 1999/5/EC

#### [Dutch]

Dit product is in navolging van de bepalingen van Europees Directief 1999/5/EC.

#### [Finnish]

Tämä tuote noudattaa EU-direktiivin 1999/5/EC määräyksiä.

#### [French]

Ce produit est conforme aux exigences de la Directive Européenne 1999/5/EC.

#### [German]

Dieses Produkt entspricht den Bestimmungen der Europäischen Richtlinie 1999/5/EC

#### [Greek]

Το προϊόν αυτό πληροί τις προβλέψεις της Ευρωπαϊκής Οδηγίας 1999/5/ΕC.

#### [Icelandic]

Þessi vara stenst reglugerð Evrópska Efnahags Bandalagsins númer 1999/5/EC

#### [Italian]

Questo prodotto è conforme alla Direttiva Europea 1999/5/EC.

#### [Norwegian]

Dette produktet er i henhold til bestemmelsene i det europeiske direktivet 1999/5/EC.

#### [Portuguese]

Este produto cumpre com as normas da Diretiva Européia 1999/5/FC.

#### [Spanish]

Este producto cumple con las normas del Directivo Europeo 1999/5/EC.

#### [Swedish]

Denna produkt har tillverkats i enlighet med EG-direktiv 1999/5/EC.

#### **European Economic Area Restrictions**

#### Local Restriction of 802.11b/802.11g Radio Usage

[Note to integrator: The following statements on local restrictions must be published in all end-user documentation provided with the system or product incorporating the wireless product.]



Due to the fact that the frequencies used by 802.11b/802.11g wireless LAN devices may not yet be harmonized in all countries, 802.11b/802.11g products are designed for use only in specific countries or regions, and are not allowed to be operated in countries or regions other than those of designated use.

As a user of these products, you are responsible for ensuring that the products are used only in the countries or regions for which they were intended and for verifying that they are configured with the correct selection of frequency and channel for the country or region of use. Any deviation from permissible settings and restrictions in the country or region of use could be an infringement of local law and may be punished as such.

The European variant is intended for use throughout the European Economic Area. However, authorization for use is further restricted in particular countries or regions within countries, as follows:

#### General

European standards dictate maximum radiated transmit power of 100 mW effective isotropic radiated power (EIRP) and the frequency range 2400 – 2483.5 MHz. The low band 5.15 - 5.35 GHz is for indoor use only.

#### Belgium

The product may be used outdoors, but for outdoor transmissions over a distance of 300m or more, a license from the BIPT is required.

This restriction should be indicated in the manual as follows:

Dans le cas d'une utilisation privée, à l'extérieur d'un bâtiment, au-dessus d'un espace public, aucun enregistrement n'est nécessaire pour une distance de moins de 300m. Pour une distance supérieure à 300m un enregistrement auprès de l'IBPT est requise. Pour une utilisation publique à l'extérieur de bâtiments, une licence de l'IBPT est requise. Pour les enregistrements et licences, veuillez contacter l'IBPT.

#### France

For Metropolitan departments:

2.400 - 2.4835 GHz for indoor use.

2.400 - 2.454 GHz (channels 1 to 7) for outdoor use.

For Guadeloupe, Martinique, St Pierre et Miquelon, Mayotte:

2.400 - 2.4835 GHz for indoor and outdoor use.

For Reunion, Guyane:

2.400 - 2.4835 GHz for indoor use.

2.420 - 2.4835 GHz for outdoor use (channels 5 to 13)

The low band 5.15 - 5.35 GHz is for indoor use only.

# **European Telecommunication Information** (for products fitted with EU-approved modems)

Marking by the symbol ( indicates compliance of this equipment to the Radio and Telecom Terminal Equipment Directive 1999/5/EC. Such marking is indicative that this equipment meets or exceeds the following technical standards:

CTR 21 - Attachment requirements for pan-European approval for connection to the analogue Public Switched Telephone Networks (PSTNs) of TE (excluding TE supporting voice telephony services) in which network addressing, if provided, is by means of Dual Tone Multi-Frequency (DTMF) signaling.



Although this equipment can use either loop disconnect (pulse) or DTMF (tone) signaling, only the performance of the DTMF signaling is subject to regulatory requirements for correct operation.

It is therefore strongly recommended that the equipment is set to use DTMF signaling for access to public or private emergency services. DTMF signaling also provides faster call setup.

This equipment has been approved to Council Decision 98/482/EEC - "CTR 21" for Pan-European single terminal connection to the Public Switched Telephone Network (PSTN).

However, due to differences between the individual PSTNs provided in different countries, the approval does not, of itself, give an unconditional assurance of successful operation on every PSTN termination point. In the event of problems, you should contact manufacturer Technical Support.

# WEEE SYMBOL INFORMATION



# **Correct Disposal of This Product** (Waste Electrical & Electronic Equipment)

#### (Applicable in the European Union and other European countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.



# **Correct disposal of batteries in this product**

#### (Applicable in the European Union and other European countries with separate battery return systems.)

This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste at the end of their working life. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66. If batteries are not properly disposed of, these substances can cause harm to human health or the environment.

To protect natural resources and to promote material re-use, please separate batteries from other types of waste and recycle them through your local, free battery return system.

#### **USA ONLY**

This Perchlorate warning applies only to primary CR (Maganese Dioxide) Lithium coin cells in the product sold or distributed ONLY in California USA.

"Perchlorate Material- special handling may apply, See www.dtsc.ca.gov/hazardouswaste/perchlorate."

Contains Mercury, Dispose According to Local, State or Federal Laws.

For details see lamprecycle.org, eise.org, or call 1-800-Samsung.

# **Overview**



#### **Before You Start!**


- Optional items may be changed or may not be provided depending on the computer model.
- The actual color and appearance of the computer may differ from the pictures used in this guide.

### **Front View**



1	Camera Lens (Optional)	Using this lens, you can take still pictures and record video.
2	Speaker	A device used to generate sound.
3	Power Button	Turns the computer on and off.
4	Keyboard	A device to enter data by pressing the keys.   ☐ 51
5	Touchpad/ Touchpad Buttons	The touchpad and touchpad buttons provide functions similar to the mouse ball and buttons. 🗏 53
6	Multi Card Slot	A card slot that supports SD Card, SDHC, and MMC cards.
7	Status Indicators	Shows the operating status of the computer.  The corresponding operating LED is lit when the corresponding function operates.   43
8	LCD	The screen images are displayed here.
9	Microphone	You can use the built-in microphone.

### Status Indicators



1	Num Lock	This turns on when the Num Lock key is pressed and numeric keypad is activated.
2	Caps Lock	This turns on when the Caps Lock key is pressed allowing capital letters to be typed without holding the Shift button down.
3	Scroll Lock	This turns on when the Scroll Lock key is pressed and screen scroll is locked.
4	HDD/ODD	This turns on when the hard disk is or ODD being accessed.
5	Wireless LAN	This turns on when the wireless LAN is operating.
6	Charge Status	This shows the power source and the battery charge status.  Green: When the battery is fully charged or the battery is not installed.  Red: When the battery is being charged.  Off: When the computer is running on battery power without being connected to AC adapter.
7	Power	This shows the computer operating status.  On: When the computer is operating.  Blinks: When the computer is in Sleep mode.

# **Right View**



1	Modem Port (optional)	A port to which a telephone cable is connected to in order to dial up to the Internet.
2	CD Drive(ODD) (Optional)	Plays CD or DVD titles. Since an ODD(Optical Disk Drive) is optional, the installed drive depends on the computer model.   56
3	USB Port	You can connect USB devices to the USB port such as a keyboard/mouse, digital camera, etc.

# Left View




1	Security Lock Port	You can connect a Kensington lock to the Security Lock Port to prevent the computer from being stolen.
2	DC Jack	A jack to connect the AC adapter that supplies power to the computer.
3	Monitor Port	A port used to connect a monitor, TV or projector supporting a 15pin D-SUB interface. 🗏 64
4	Wired LAN Port	Connect the Ethernet cable to this port.
	Digital Video/Audio Port	You can connect an HDMI cable to this port.
5	(HDMI)	Using this port, you can enjoy digital video and audio on the TV.
		This port can be used to connect a USB or eSATA device.
6	eSATA/USB Common Port	Windows XP does not support eSata.
	Chargeable USB Port	You can connect USB devices to the USB port such as a keyboard/mouse, digital camera, etc. (Chargeable USB: You can charge USB devices through the USB port even when the computer is turned off.)
7		<ul> <li>Charging a device through a Chargeable USB takes longer than using a regular charger.</li> <li>Press the F2 key when the Samsung logo appears in the booting sequence to enter the BIOS Setup, select Advanced &gt; USB Charge In Sleep Mode, and set it to Enable. Then you can use the Chargeable USB Port feature even in sleep mode.</li> </ul>
8	Microphone Jack	A jack used to connect the microphone.
9	Headphone Jack	A jack used to connect the headphones.
10	ExpressCard Slot (Optional)	Install the Express card into this slot.

### **Back View**



1	Battery	This is a Lithium-Ion rechargeable battery that supplies power to the computer. 🗉 134	
2	Fan Vents	The internal heat of the computer is emitted through these holes.	
		If the vents are blocked the computer may overheat.  Avoid blocking the vents as this may be dangerous.	

### **Bottom View**



1	Battery Latches	The latch used to remove or install the battery. 🖹 134
2	Sub-Woofer Speaker (Optional)	A device used to produce mid and low frequency sound louder.
3	Memory Compartment Cover	The main memory is installed inside the cover.  ☐ 132
4	Hard Disk Drive Compartment Cover	The hard disk drive is installed inside the cover.

# Turning the Computer On and Off

#### Turning the computer on

- Install the **battery** and connect the **AC adapter**. (Refer to the **Installation Guide**.)
- Lift the LCD panel up.
- Press the Power button to turn the computer on.



Power button LED is lit while the computer is turned on.






- If you press and release the Power button on the computer when it is on, the computer enters Sleep mode.
- When running the computer on battery power, the LCD brightness is dimmed automatically to save battery power.
  - Press the **Fn+** 1 key to increase the LCD brightness.  $\equiv$  52
- When turning the computer on for the first time, the Register Windows screen appears. You can use the computer after registering your user information.

#### **Turning the computer off**

- Click the **Start** button on the taskbar.
- Click the and click on **Shut down**.
  The computer will shut down.





#### **Before Using the Power Button**

Since the Power Icon is set to power saving mode, selecting **Start > Power Button** will cause the computer to enter **Sleep mode**.

To shut down the computer by clicking this icon, refer to the descriptions for Setting up Start menu power button of the Control Panel.  $\boxed{90}$ 




If the system cannot be shut down due to a system error, turn it off by pressing and holding the Power Button for a minimum of 4 seconds.

Please note that turning the computer off by this method may cause a system problem. Thereafter, when turning the computer back on, the disk checking program may launch to check for and correct any disk errors.

# Chapter 2.

Using the computer



Keyboard	51
Touchpad	53
CD Drive (ODD, Optional)	56
Inserting and Ejecting a CD	56
Multi Card Slot	58
ExpressCard Slot (Optional)	61
Connecting a monitor / TV	62
Connecting to the Monitor / TV	62
Viewing Through a Monitor / TV	64
Using Dual View	68
Adjusting the Volume	70

# Keyboard

Shortcut key functions and procedures are discussed in the following sections.



- The keyboard is supplied according to the corresponding country.
- The keyboard may differ depending on your country. The following mainly describes the shortcut keys.

#### **Shortcut Keys**

You can use the following functions by pressing the keys below with the **Fn** key.























Fn+	Name	Function
Esc	REST (Sleep Mode)	Switches to Sleep mode. To wake the computer up, press the Power button.
F2	Gauge	Shows the remaining battery charge. You can only use this function when the Easy Display Manager program is installed.
F3 €	Euro	Enters the Euro monetary unit symbol. This key may not be provided depending on the keyboard type.
F4	CRT/LCD	Switches the screen output to the LCD or external monitor when an external monitor (or TV) is connected to the computer.   64
<b>F5</b> ★	Backlit	Turns the LCD backlight on or off.
F6 🖎	Mute	Mutes or cancels mute.
F7	Samsung Magic Doctor	System diagnosis, recovery and Internet consultation program, Samsung Magic Doctor, will be launched.

Fn+	Name	Function
	Easy SpeedUp Manager	You can select operation mode when you need maximum system performance or low-noise/low power consumption with one-click.
(50)		Silent: Low-noise and low power consumption mode
F8 🤺		Normal: Normal Mode
		• <b>Speed:</b> Maximum performance mode. The system operates in its maximum performance, and system resources are allocated to the currently active program with priority for maximum performance.
<b>F9 ▼</b>	Wireless LAN	Turns the wireless LAN function on or off in models with wireless LAN capability.
F10		Turns the Touchpad function on or off.
	Touchpad	When using an external mouse only, you can turn the Touchpad off.
F12	Scroll Lock	If you turn the Scroll Lock on, you can scroll the screen up or down without changing the cursor location in some applications.

#### **Screen Brightness Control**

To adjust the LCD brightness press the  $\mathbf{Fn} + \left[\begin{array}{c} \uparrow & \\ \downarrow & \end{array}\right]$  key combination or the  $\mathbf{Fn} + \left[\begin{array}{c} \downarrow & \\ \downarrow & \end{array}\right]$  key combination.

The changed screen brightness is displayed at the center of the screen for a moment.

#### **Volume Control**

To control the volume, press the  $\mathbf{Fn}$  +  $\frac{\mathbf{Fn}}{\sqrt[4]{\mathbf{F}}}$  key combination or the  $\mathbf{Fn}$  +  $\frac{\mathbf{Fn}}{\sqrt[4]{\mathbf{F}}}$  key combination.

You can mute the sound or cancel the mute function by clicking the Fn +  $^{\lceil 6 \rceil}$  key combination.

#### **Other Function Keys**

Application Key 🖪

Performs the right-click mouse function (touchpad).


# **Touchpad**

The touchpad provides the same function as a mouse and the left and right buttons of the touchpad plays the role of the left and right buttons of a mouse.



#### **Before You Start!**

- Use the Touchpad with your fingers. Using a sharp object may damage the Touchpad.
- If you touch the Touchpad or press the Touchpad buttons while booting up, the Windows boot time may be extended.






To deactivate the touchpad LED function or to keep the LED on, change the setting by selecting **Advanced > Touch Pad LED** in the BIOS Setup.

#### Moving the cursor on the screen

Place your finger on the touchpad slightly and move your finger.


The mouse cursor will move accordingly. Move your finger in the direction you wish to move the cursor.



#### **Double-Click Function**

Put your finger on the touchpad and quickly tap twice with your finger on an item you want.


Alternatively, press the left touchpad button twice quickly.



#### **Click Function**


Place your finger on the touchpad and tap your finger once over an item you want.

Alternatively, press the left touchpad button once.



#### **Right Button Function**


This corresponds to clicking the right mouse button. Press the right touchpad button once. The corresponding pop-up menu appears.



#### **Drag Function**

Dragging refers to moving an item to another place after selecting it.


Press and hold down the left touchpad button over an item you want to drag and move the item to the new location.



#### **Touchpad Scroll Function**

The touchpad scroll area provides the mouse wheel function (scroll function).

Place your finger on the touchpad's right edge for vertical scrolling or the bottom edge for horizontal scrolling and then move your finger along the edge to scroll the screen vertically or horizontally.



#### **Touchpad On/Off Function**

If you want to use the mouse only without using the touchpad, you can turn the touchpad off.

To lock the touchpad function, press the  $\mathbf{Fn} + {}^{[F10} \boxtimes ]$  keys.



You can set the touchpad and touchpad button settings in the tabs that appear when clicking **Start > Control Panel > Hardware and Sound > Mouse**.

# CD Drive (ODD, Optional)

An optical disk drive is optional and may differ depending on your computer model. For detailed specifications, refer to the catalogue.



#### **Before You Start!**

One of the following optical disk drives is installed on this computer or may not be provided depending on your computer model.

Drive Type	Function
DVD Super Multi	You can read CDs and DVDs, and burn CDs and DVDs. Supported DVD recording types include DVD±R, DVD±RW, DVD-RAM.
DVD Super Multi LS (LightScribe)	<ul> <li>You can read CDs and DVDs, and burn CDs and DVDs.</li> <li>Supported DVD recording types include DVD±R, DVD±RW, DVD-RAM.</li> <li>Print an image or text onto the surface of a CD/DVD.</li> </ul>
BD-ROM (Optional)	You can read CDs, DVDs and BDs.
BD-Combo (Optional)	You can read CDs, DVDs and BDs and burn CDs and DVDs.



- Do not insert a cracked or scratched CD.
   Otherwise, the CD may break and damage the optical disk drive when the CD rotates at a high speed.
- When you clean a CD or DVD title, wipe with a soft cloth from inside to outside.
- DVD Super Multi LS (LightScribe) or Blu-Ray drive is only available for some models.
- Insert a Mini CD into the center of the CD drive.

#### **Inserting and Ejecting a CD**

Click the **Eject** button of the optical disk drive at the side of the computer.



When the CD tray opens, insert a CD or DVD and push the tray in until it clicks.



Push the CD tray inward until it clicks.

The CD drive status indicator is turned on.



- A CD drive's reading and writing speed may differ depending on the condition and type of the media.
- To eject a CD when the CD drive does not work or the computer is off, place the end of a paper clip ( ) into the Emergency Hole until the CD tray is ejected.

#### **Using LightScribe (Optional)**

LightScribe is a feature that allows you to print letters or images onto the surface of a CD/DVD when recording data.

LightScribe's features are provided for DVD Super Multi drives (ODDs) that support LightScribe.

If the LightScribe logo with is on the surface of the CD drive (ODDs), it means the LightScribe feature is supported.

For models supplied with **Cyberlink DVD Suite**, you can print a label using the **LabelPrint** function of **Cyberlink DVD Suite**.

For detailed procedures on using this function, refer to the help section of the program.



- Even if the Disk label print program is installed on your computer or the LightScribe Control Panel program icon is in the system tray of the Taskbar, you cannot use the LightScribe function, if your CD-ROM drive (ODD) does not support this function.
- If the LightScribe menu is not shown in CyberLink Label Print even for a model that supports LightScribe, please go to http://www.lightscribe.com/ and download the latest version of LightScribe.

# Multi Card Slot

Using the multi card slot, you can read and write data to a SD card, SDHC card, MMC card.

You can use a card as a removable disk and conveniently exchange data with digital devices such as a digital camera, digital camcorder, MP3, etc..



#### **Before You Start!**

- You have to additionally purchase a multi card with the necessary capacity depending on your requirements.
- You can use a multi card just like any data storage device. A copyright protection function is not supported.
- Since you can lose a card when moving the computer, keep the card separately.

#### **Supported Cards**



**SD Card** 



SDHC card



MMC


#### To Insert and Use a Memory Card

Insert a card into the slot according to the directions printed on the slot.



The card drive appears. Click **Open folder and view files**.

If the window does not appear, click **Start > Computer**.





If a window asking to scan and change appears, click **Continue Without Scanning**. This will proceed to Step 2 above.

You can save, move and delete data by doubleclicking the corresponding drive.





The device name of the card drive may differ depending on your computer model.

You can only use the card after formatting it.



#### Using a Mini SD and RS-MMC

Since the above cards are too small, you cannot insert the cards into the slot directly.

Insert the card into the dedicated adapter (available from most electronic retailers) and then insert the adapter into the multi card slot.

However, depending on the adapter's body material, some RS-MMC cards may not be recognized properly. Samsung recommend that you check the card is recognized correctly prior to purchasing.

#### To remove a memory card

Take hold of the end of the card and remove the card.

#### To format a memory card

When using the memory card for the first time, you must format the card before using it.



Formatting a card deletes all data saved on the card. If the card includes data, backup the data before formatting it.

- Click Start > Computer.
- Right-click over a card drive with the touchpad and select Format.
- Click Start to the formatting.



- To use a card to exchange data with a digital device such as a digital camera, formatting the data using the digital device is recommended.
- When you try to use a card, which is formatted in the computer, in another digital device, you may have to format the card again in the device.
- You cannot format, write or delete data from a SD, or SDHC card with a write protection tab when it is in the Lock position.
- Inserting and removing a memory card repeatedly may damage the memory card.

# **ExpressCard Slot** (Optional)

You can use Express cards using this slot.

The ExpressCard slot can be regarded as the next generation PCMCIA card specification and supports LAN, TV Tuner and Sound cards. This computer's slot supports the Express Card/54 specification.



#### **Before You Start!**

- Remove the dummy card installed to protect the slot first. Lightly push the dummy card of the slot. The dummy card pops up. Eject the dummy card.
- This slot is a ExpressCard slot. You cannot connect a PCMCIA card here.

#### To insert a card

Insert a card into the slot on the side of the computer.



If you insert a card into the slot, Windows recognizes the card automatically or a message telling you to install a driver appears.

If the card is not automatically recognized, install the device driver supplied with the card.



If a window asking whether you want to scan and change appears, click on Continue Without Scan. This will proceed to Step 2 above.

#### To remove a card

Double-click the Safely Remove Hardware icon on the taskbar.



- Select the card to be removed and click **Stop**.
- If the **Stop a Hardware device** window appears, click the **OK** button.
- Push the card in the slot lightly. Then the card pops up.
- Eject the card.

# Connecting a monitor / TV

Using an external display device is useful when you are giving a presentation or watching a video or movie through your monitor.



#### **Before You Start!**

You have to buy a connection cable additionally.

#### **Connecting to the Monitor / TV**

#### **Connecting to the Monitor port**

Connect the computer to the RGB port of the monitor or TV using a monitor cable (15-pin).



#### **Connecting to the HDMI port**

Connect the computer to the HDMI port of the monitor or TV using a HDMI cable.





- When connecting the computer to a TV, switch the external input mode of the TV to 'HDMI'.
- When a TV provides more than one HDMI port, connect the computer to the "DVI IN" port.

#### Viewing Through a Monitor / TV

You can switch the display device using the shortcut key.

# **Switching the Display Device using the Shortcut Key**

Press the  $Fn + {}^{F4}$  key combination once. Then the **Easy Display Manager** screen appears in which you can select a display device.

Whenever you press the  $\frac{f^4}{80}$  key while holding down the **Fn** key, the selected option is changed.



**Example) Selecting LCD+CRT Dual View** 



- LCD: Notebook Screen
- CRT: External Monitor Screen
- HDMI: TV Screen or Monitor (when it is connected via the HDMI port).
- LCD+CRT Clone : Notebook+ External Monitor Screen
- LCD+CRT DualView: Notebook+ External Monitor Screen in Dual View
- LCD+HDMI Clone: Notebook+ TV(or Monitor) Screen
- LCD+HDMI DualView: Notebook+ TV(or Monitor)
   Screen Dualview

#### What is Dual View?

Dual View is a function that enables you to view a computer screen over two display devices. It is convenient when you need a wide screen.



- The TV screen is only supported for models that support the TV output port (HDMI).
- Simultaneous output to all 3 (LCD + CRT + HDMI) is not supported.
- External Monitor / TV is not supported in the DOS Command Prompt window.

#### **Setting up HDMI TV video**

If the Desktop screen displayed on the TV does not fit to the TV screen, configure it as follows depending on the graphics card.



- You can view the graphics card type by selecting Start > Control Panel > Hardware and Sound > Device Manager > Display adapters and then clicking the + symbol.
- The screen images and terms may differ from actual product depending on the computer model and driver version.

#### • For ATI graphics cards

Right-click over the Desktop and select ATI Catalyst Control Center > Advanced and click Next.




2 In the **Graphics Setting** window, select the **DTV(HDMI™)2 > Scaling Options**.




Fit the Desktop to the TV screen by sliding a resize bar and click **OK**.

- For Intel graphics cards
- Right-click over the Desktop and select **Graphics Properties**.
- Click **Display Settings** and click the **Aspect Ratio Options**.



Fit the Desktop to the TV screen by sliding the Horizontal and Vertical Resize Bars and click **OK**.



#### **Setting up HDMI TV audio**

You can configure the sound of the computer to be played through the HDMI TV. You have to configure the sound device in the Control Panel whenever you connect the HDMI TV in order to hear sound from the computer on the TV.




The screen images and terms may differ from actual product depending on the computer model.

Right-click over the **Volume** Control icon (1) in the notification area at the bottom right of the Desktop and select **Playback Devices**.

(Alternatively, click the **Control Panel > Hardware and Sound > Sound**.)

If the default Playback Device is set to **Speakers**, change it to **Digital Output Device(HDMI) (or HDMI Device)**, click **Set Default** and then click **OK**.





HDMI Output Device may not appear on the playback device list depending on the computer model.

In this case, turn on the TV, connect the TV to the computer using a HDMI cable and then switch to HDMI or LCD+HDMI Clone or LCD+HDMI DualView mode using the Shortcut Key(Fn + F4).



To listen to sound on the computer after disconnecting the HDMI TV, you have to set the Playback Device to **Speakers**.

#### **Using Dual View**


Dual View enables users to expand their computer screen over two display devices.

Dual View is convenient when a wide operating space is needed. In addition, since Dual View operates as if there are 2 graphic cards present even when there is only one, you can set the resolution and color for each display device.


#### **Selecting Dual View**

Check if the external display device is properly connected and follow the instructions below.

- Click the Start > Control Panel > Appearance and Personalization > Adjust screen resolution.
- Click on the number 2 monitor icon and select Extend the desktop onto this monitor. Click Apply and then click the OK button.




When notebook LCD is set as the main device, the 1 digit is displayed over it and the 2 digit is displayed over the auxiliary display device. Now you can expand the Desktop screen over 2 display devices. When using Dual View, it is recommended setting the LCD as the main device (number 1).



If the resolution of the auxiliary display device is 640×480 pixels with 256 colors, click the **Start > Control Panel > Appearance and Personalization > Adjust screen resolution > Monitor Number 2** and adjust the resolution and color quality.

#### **Using Window in Dual View**

Click on the window title bar of the main LCD (monitor number 1) and drag it into the auxiliary display device (monitor number 2) to move the window.



#### **Canceling Dual View**

- Click the Start > Control Panel > Appearance and Personalization > Adjust screen resolution.
- Click on the Monitor Number 2 icon, unselect Extend the desktop onto this monitor, and then click Apply.

# Adjusting the Volume

You can adjust the volume using the keyboard and the volume control program.


#### Adjusting the Volume using the Keyboard

Press the **Fn** + key combination or **Fn** + key combination to adjust the volume.


Press the  $\mathbf{Fn} + \frac{f6}{4}$  key combination to turn the volume on or off.

# **Adjusting the Volume using the Volume Adjustment Program**

Click the **Volume** icon  $\P$ ) on the taskbar and slide the volume control bar to adjust the volume.



Alternatively, right-click over the **Volume** icon (1) and select **Open Volume Mixer** to adjust the volume.



#### **Using the Sound Recorder**

The procedures to record sound using the Windows Recorder are described below.

- Connect a microphone to the microphone jack.
- Right-click over the **Volume** icon (1) on the taskbar and select **Recording Device**.
- Check if the microphone is set as the default recording device.

If this is the case, it is already set as the default device. If not, right-click over the microphone and select **Set default**.

Click Start > All Programs > Accessories > Sound Recorder and click Start recording to start a recording.




#### **Using SRS**

The SRS function enables you to experience more stereophonic sound using stereo speakers.

- Right-click over the **Volume** icon (1) in the Taskbar and select **Play Device** (P).
- Select Speaker in the Play tab and click Properties.

Select the **SRS tab** in the **Speaker Properties** window. Select a mode and click the **Use** checkbox on the left. Click **OK**. You will be able to experience a more stereophonic sound in the selected mode.



- WOW HD (Music): Select to listen to music.
- TruSurround XT (Movie/Video): Select to watch a movie.



- The SRS function is only supported for a computer's built-in speakers or headphones.
- It is recommended to unchecking the SRS option before recording, and to check it before play. It is to prevent sound distortion because of double application of SRS effect when user plays the file recorded by using stereo mix.

# Chapter 3.

# **Using Microsoft Windows Vista**

About Microsoft Windows Vista	7:
Welcome Center	7:
Help and Support	7
Windows Vista Screen Layout	7
Desktop	7:
Start Menu	7
Sidebar / Gadget	7
Window	8
Control Panel	8
Opening the Control Panel	8
User Accounts	8
Changing the screen resolution and the color	8
Configuring the Start Menu Power Button	9
Phishing Filter	9:
User control function	9
Windows Mobile Center	9

The screen shots used in this chapter may differ from actual screens depending on the Windows Vista version and model.

# About Microsoft Windows Vista

**Microsoft Windows Vista** (hereafter Windows) is a computer operating system. Since you have to learn how to use it in order to use the computer efficiently and effectively, use the **Welcome Center** and **Windows Help and Support** to learn about Windows Vista.




The screen layout may differ depending on the computer model and the operating system.

#### **Welcome Center**

In the Welcome Center, you can view brief descriptions of Windows Vista functions and run the functions directly.

- If you click on an item, information on the function is displayed in the description window.
  For example, if you click View computer details, your computer information is displayed in the description window.
  In addition, click on Show More details, for more detailed information.






#### Windows Vista Demo

If you click **Start > Welcome Center > Show all x items > Windows Vista Demo**, you can watch the Windows Vista introduction movie.

# **Help and Support**

Windows Help and Support provides information on Windows basic functions and usages.

You can find help for frequently used basic functions using Find an Answer and you can search for help by entering a keyword in the Search box.



Windows Basics	*	Introduces the basic usage of the computer and the Windows operation system. You can learn tasks and tools necessary to use the computer.
Security and Maintenance	***	You can view help on computer protection and security.
Windows Online Help		If your computer is connected to the Internet, you can view the necessary information online.
Table of Contents		The help pages are arranged by subject so that users can easily find the relevant information.
Troubleshooting	?	You can view possible problems that may occur while using Windows and solutions to the problems.
What's new?	<b>9</b>	You can view help for new Windows Vista features.

# Windows Vista Screen Layout

# **Desktop**

If you turn the computer on, the Desktop screen appears.

The desktop is the working area on the computer. It consists of a large workspace and a taskbar at the bottom as shown in the figure below.



The screen layout may differ depending on the computer model and the operation system version.



1 Recycle Bin	You can drop useless files and folders here.
2 Shortcut Icons	You can launch programs by clicking the shortcut icons on the Desktop.
3 Start Menu	The menu from which you can launch programs.
4 Start Button	Press the start button. The Start menu appears.
5 Taskbar	Currently running programs are displayed here.
6 System Tray with Clock	Shows some running program icons. Icons not being used are hidden. If you click the arrow mark on the left, you can view hidden icons. This is a mini information program that appears on the Sidebar.
7 Sidebar	This is a vertical bar that appears at the side of the Desktop.
8 Gadget	This is a mini information program that appears on the Sidebar.




Some items may not be provided depending on the Windows Vista version.

# **Start Menu**

The menu from which you can launch programs.

Alternatively, press the **Windows** key 🚱 on the keyboard.



Search	۶	Enables users to search for files and folders.
Computer		Shows storage devices such as hard disk drives, CD/DVD drives, network drives, etc. In addition, you can manage files and folders here.
Control Panel		Enables users to configure the appearance and settings of Windows such as the Desktop, window colors, hardware and software settings, security, etc.
Help and Support	?	Provides on-line help about functions and usage of Windows and troubleshooting. You can find a solution to a problem by entering a keyword.
Power Button	(b)	Click the Power button to enter Sleep mode.  However, how the power button functions changes according to the power button settings.
Lock Button		To lock the computer, click this button. If you lock your computer, no one can use the computer until you enter the password.
Power Menu Button	-	Click the Power Menu button to shut down, restart, and logoff from the computer.

### Sidebar / Gadget

Sidebar is a vertical bar that appears at the side of the Desktop.

A mini program called Gadget runs over the Sidebar which shows information such as stocks, schedule, weather, etc. and provides frequently used tools.

You can download various Gadgets from the Internet other than the default Gadget.

#### Sidebar / Gadget Structure

If you launch Windows, the Sidebar is automatically launched and the Sidebar and Gadget appear at the side of the Desktop.





- If the Sidebar is not launched automatically when Windows starts, click Start > All Programs > Accessories > Windows Sidebar to launch it manually.
- To always display the Sidebar, right-click over the Sidebar and select Properties and then select the Sidebar is always on top of other windows option in the Arrangement field.

#### **Adding a Gadget**

You can find a gadget in the Gadget Gallery and add it to the Sidebar.

✓ If you click the + at the top of the Sidebar, the Gadget Gallery opens.




If you double-click on a gadget, the gadget is added to the Sidebar.



- You can move a gadget to another location by dragging it with the mouse.
   Not only can you move a gadget onto the Sidebar but also out of the Sidebar.
- If you place the mouse pointer over a gadget, the close and option buttons appear.

### **Exiting the Sidebar**

Right-click on the **Sidebar** icon in the System Tray with the clock on the taskbar and select **Exit** to exit the Sidebar.





#### Closing the Sidebar

- Even if you close the Sidebar, the Sidebar continues running in the System Tray in the clock area, though it is not displayed on the Desktop.
- To close the Sidebar, right-click over the Sidebar on the Desktop and select **Close Sidebar**.

  To open the Sidebar again, right-click on the Sidebar icon in the System Tray with the clock on the taskbar and select **Open**.


### **Window**

A window is the basic frame for a computer operation. As an example, let's see the layout of a **Pictures Window**.



The items and names may differ depending on your computer model and the Windows Vista version.

### **Window Layout**



1 Address Display Line	Shows the location of the currently selected folder or file.
2 Move Button	You can move to the previous or next page by clicking the Back or Next buttons.  Opens the previously opened page.  Opens the next page, when you have returned to a previous page.
3 Toolbar	Provides icons to quickly run frequently used functions.
4 Search Window	You can view the drive structure and the currently opened window location.  You can move directly to a folder by clicking the folder in the Search window.
5 Window Button	Used to resize the window.  Minimizes the window.  Maximizes the window.  Closes the window.
6 Search Box	You can search for files by specifying the text included in the filename or within the file or file attributes.
7 Sort Order	Used to change the sort order of the files.
8 Folder / File	The drives, folders and files included on the computer are displayed here.
9 Detailed Information Window	Shows the general information of the selected file.



#### • What is a drive?

A storage device on which files and folders are saved to and read from.

#### • What is a folder?

A folder is used to systematically group and manage files, and may include files in sub-folders. It is similar to a filing cabinet.

#### • What is a file?

A file is a document or various kinds of information generated as a result of a program operation. This is also called data.

#### **Window View Functions**



- If you have set up the Aero function, you can use the window view functions.
- If you want to use the Aero function, click Start > Control Panel > Appearance and Personalization > Window Color and Appearance. Select Enable Transparency and Click OK. If Appearance Settings window appears, select Windows Aero from the color scheme and click OK.

#### O Preview

If you move the mouse pointer over a window button on the Taskbar, you can preview the contents of the window without opening it.




#### Switching between Windows

This function arranges multiple windows in 3D so that users can easily view the windows.

Press the **Windows** logo + **Tab** keys or click on **Switch Windows** at the bottom left of the Desktop, and the windows are displayed in 3D.






# Control Panel

Tools for configuring Windows are located in the Control Panel.

# **Opening the Control Panel**



System and Maintenance		Using this function, you can configure Windows performance options.
Security		Using this function, you can check the current security status to protect the computer and configure the security settings for the firewall, spyware, etc.
Network and Internet		Using this function, you can check the network status and configure the settings. You can change the Internet connection settings.
Hardware and Sound	<b>SO</b>	Using this function, you can add a printer and other hardware, change the settings, and update the device drivers.
Programs		Using this function, you can remove a program or Windows function and download a new program from the internet.
Mobile PC		You can set up the mobility, power option and personal settings for your mobile PC. You can also synchronize your mobile PC with another portable device or network folder.



User Accounts and Family Safety	<b>S</b>	You can change the user account settings, passwords and configure the Parental Controls function.
Appearance and Personalize		Using this function, you can configure the Desktop style, theme or screen saver settings.
Clock, Language, and Region		Using this function, you can configure the date, time, language and regional settings.
Ease of Access		Using this function, you can select options for hearing and sight impaired persons as well as for challenged persons. You can configure the audio recognition settings.
Additional Options	<b>%</b> =	Using this function, you can configure other Control Panel item settings.

### **User Accounts**


Using Windows Vista User Accounts, more than one user can easily share the same PC.

The procedures to add and delete a user account and to switch users are described below.

#### **Adding User Accounts**

- Click Start > Control Panel> User Accounts and Family Safety.
- Click User Accounts > Manage another account.
- 3 Click Create a new account.
- Enter a new **username** and select either Standard User or Administrator.

Click Create a new account to add a new account.




#### **Removing User Accounts**



- If there is only one administrator account for the computer, you cannot delete the administrator account.
- You can only delete another account when you are logged in as an administrator.
- Click Start S > Control Panel > User Accounts and Family Safety > User Accounts.
- Click Manage Another Account.
- Click on the user account to be deleted.
- Click **Delete the Account** in the Make changes to user's account menu.
- A window appears asking whether you want to save the desktop, documents, favorites, music files, pictures and video folders as new folders on the Desktop before deleting the account.


If you click **Delete files**, the account and all files belonging to the account are deleted.

If you click **Keep files**, only the account is deleted and the files belonging to the user are saved on the Desktop.



### **Switching User Accounts**

Click **Start** on the taskbar and select **Switch User**.



2 If you click on another username in the start screen, you can login with that user account.


# Changing the screen resolution and the color

The resolution refers to the number of pixels displayed on the screen. When increasing the resolution, the items on the Desktop become smaller and more items can be displayed on the screen. The higher the color quality, the more colors are displayed on the screen.

- Click Start > Control Panel > Appearance and Personalization > Personalization > Display Settings.

  Alternatively, right-click on the Desktop and select Personalization > Display Settings from the pop-up menu.
- The Display Settings screen appears.

  Change the resolution and color settings and click the **OK** button.






The following resolutions and color qualities are recommended according to the computer LCD panel type.

LCD Type	Resolution	Color Quality
17.3" HD+	1600 x 900	Very High (32bit)
17.3" HD+	1680 x 945	Very High (32bit)
17.3" FHD	1920 x 1080	Very High (32bit)

### **Configuring the Start Menu Power Button**


The **Power button** on the Start menu performs various operations depending on the settings.

Click Start > Control Panel > Hardware and Sound > Power Options and then Change Battery Settings.



2 Click on **Change Plan Settings** in the currently selected power setting.

Click on Change Advanced Power Settings and open Start Menu Power Button in the Power Buttons and Lid item.





Select a power plan and click the **OK** button.

Туре	Description	Power Button Image after Setting Change
Sleep	Sets the computer to enter Sleep mode.  The screen and hard disk will be turned off to reduce the power consumption of the overall system.	
Оівер	If you press the <b>Power button</b> on the computer, Sleep mode is deactivated and you can start working immediately.	O
Hibernate	Sets the computer to hibernate.  All work is automatically saved, the screen is turned off and the computer makes no noise. If you press the <b>Power button</b> of the computer main body, the work environment is restored and you can start working immediately.	
Shut down	Shut down the computer.  You have to shut down the computer after closing all programs and opened folders.	0



- The Power button is set to Sleep mode by default.
- If the computer is set to download Windows updates automatically, the update mark is displayed on the Power button when an update is ready.
   If you click this button, the update is installed and the computer is shut down when the update installation is complete.

### **Phishing Filter**


Phishing is a method used by hackers to illegally collect personal information such as credit card numbers, passwords, other account numbers, etc. through emails or websites.

The Phishing Filter protects users from these phishing attempts.

If the current page is judged to be a suspicious website, the Phishing Filter displays a warning message with an alarm when the Phishing Filter is enabled. In addition, if a page that the user is currently trying to open is registered as a known Phishing website list, it displays a warning page instead.


#### **Phishing Filter Settings**

- Launch Internet Explorer.
- Select Tools from the menu and click Phishing Filter > Phishing Filter Settings.



The Internet Options window opens.

Locate the Phishing Filter item in the Settings field. Select **Turn on automatic website checking** and click the **OK** button to use the Phishing Filter.




To not use the Phishing Filter, select **Turn off automatic website checking** in the Settings field in Step 3 above.

#### **User control function**

Using this function, you can control the content your children can access. You can determine for how long they can use the computer and the content they can access. When you have finished the settings, click OK to finish.

#### **Configuring Parental Controls**


- Select a user to configure the Parental Controls for.
  The User Controls window for that user opens.
- Click **Parental Controls > Use** and configure the necessary settings in the **Windows Settings** at the bottom. If you click **OK**, the Parental Controls setting is completed.




#### **Using Activity Report**

You can view and evaluate your children's internet access through the Activity Report.

- Open the **User Controls** window referring to the descriptions of **Parental Controls**.
- Set Activity Reporting to On.



- To view the Activity Report, click on **View Activity Report** on the right of the **User Controls** window.
- 4 If you click the **View Activity Report**, the following window opens displaying a computer operating summary.



#### **Windows Mobile Center**

Using Windows Mobile Center, you can easily configure computer settings such as the volume, the wireless network connection settings, the display settings, etc. all at the same time.



Some functions may not be supported depending on the Windows Vista version.

Click Start > All Programs > Accessories > Windows Mobile Center.

Alternatively, click Start > Control Panel > Mobile PC > Windows Mobile Center.



2 Configure the volume, the battery status, the external display, the Sync center, etc. according to your requirements.



- Configurable items may differ depending on the installed Windows Vista version or programs.
- If Easy Network Manager program is installed, you can see Easy Network Manager window.
- If you turn the wireless LAN off in the Mobile Center, this is not reflected by the wireless LAN LED.

# Chapter 4.

**Using the Network** 

Osing the Network	
Wired Network	9
Wireless Network	10
Connecting to a Wireless LAN	10
Using the Easy Network Manager (Optional)	10
Network Settings	10
Using in Another Location	10
Diagnosing the Network Status	10
Connecting with a Modem (Optional)	10
Bluetooth (Optional)	10
Bluetooth Function	10
Using Bluetooth	10

# Wired Network

A wired network is a network environment used for a company network or broadband internet connection at home.



#### **Before You Start!**


You can also configure the network settings using the Easy Network Manager. 🗏 103

Connect a LAN cable to the computer's LAN port.



- Click Start > Control Panel > Network and Internet > Network and Sharing Center.
- Click **Manage Network Connections** from the left pane.


Right-click over the **Local Area Connection** and select **Properties**.





The LAN Device name may differ depending on your computer's Network Device.

Select Internet Protocol Version 4 (TCP/IPv4) from the Networking tab and click Properties.






- The LAN device driver may differ depending on your LAN device model.
- To add a network component, click Install in the screen shown in the figure above. You can add clients, services, and protocols.

Configure the IP settings.

When using DHCP, select **Obtain an IP address automatically**. To use a static IP address, select **Use the following IP address**, and set the IP address manually.





When not using DHCP, ask your network administrator for the IP address.

When you have completed the settings, click the **OK** button.


The network settings have been completed.

# Using both DHCP and a fixed IP simultaneously

Using the **Alternate Configuration** providing by Windows Vista, you can set both automatic and fixed IP addresses and then you can select to use either of them to connect to the Internet.

- Click Start > Control Panel > Network and Internet > Network and Sharing Center and click Manage Network Connections in the left pane.
- 2 Right-click over the **Local Area Connection** and select **Properties**.
- Select Internet Protocol Version 4 (TCP/IPv4) from the Networking tab and select Properties.

Select the Alternate Configuration tab, select User configured and fill in the corresponding fields.



When you have completed the settings, click the **OK** button.

# Wireless Network

A wireless network (Wireless LAN) environment is a network environment that enables communicating between multiple computers at home or a small-size office through wireless LAN devices.



#### **Before You Start!**

• The descriptions below are for computer models with a Wireless LAN card or device. You can also configure the wireless network settings using the Easy Network Manager. 
☐ 103

A Wireless LAN device is optional. To view the installed wireless LAN card, click **Start > Control Panel > Hardware and Sound > Device Manager > Network Adapter** and click the + symbol.

The pictures in this manual may differ from the actual product depending on your wireless LAN device model.

• To use the wireless LAN, you have to turn the wireless LAN on first by pressing the Fn + F9 y keys. If the wireless LAN is turned on, the Wireless LAN LED is lit.

#### **Wireless LAN Connections**

Wireless network connections can be classified into 3 categories and this manual describes the connection procedures for connecting through an AP.

#### Access Point (AP)

You can connect to the Internet or another computer on the network through an AP.



#### What is an Access Point (AP)?

An AP is a network device that bridges wired and wireless LANs, and corresponds to a wireless hub in a wired network. You can connect multiple wireless LAN installed computers to an AP.

#### Wireless Ad-Hoc Network Type

This connects computers with wireless LAN communications capability.


Communication is enabled by constructing an Ad-Hoc network via one computer and connecting another computer through a wireless connection.

For more detailed connection procedures, refer to the descriptions that appear when selecting Start > Help and Support > Table of Contents > Networking-connecting computers and devices > Setting up a network > Setting up a computer-to-computer (ad hoc) network.

### **Connecting to a Wireless LAN**

If there is an AP, you can connect to the Internet via the AP using the Wireless LAN connection method provided by Windows Vista.

Right-click over the **Network Connections** icon on the taskbar and click **Connect to the Network**.



Select an AP to connect to and click **Connect**.

If there is a configured network key for the AP to connect to, the Enter Network Key window appears.

Enter the network key in the window and then click the **Connect** button.






When **Connected** to the AP is displayed, click the **Close** button.

You can access the network.

#### Checking the network connection status

Move the mouse pointer over the **Wireless Network Connection** icon on the taskbar, and the connection status is displayed.



# Using the Easy Network Manager (Optional)

Easy Network Manager is a program that helps configure the network settings.

Easy Network Manager provides the following features.

- You can easily configure the network and printer settings. 

  103~104
- You can immediately use the network without having to define new network settings again after moving to another location. 


  105
  - By configuring the network settings (IP address, printer settings, etc.) for each location, you can immediately access the network without following the network setting procedures each time regardless of your location.

### **Network Settings**

This section describes the procedures to connect to the Internet by setting up a network. The setting up procedures include procedures to add a printer to the network.

- To use a wired LAN, connect the LAN cable to the LAN port.
  - To use the wireless LAN, you have to turn the wireless LAN on first by pressing the **Fn** + [F9] keys. If the wireless LAN is turned on, the **Wireless LAN LED** lights up.
- Click Start > All Programs > Samsung > Easy Network Manager > Easy Network Manager.
- Click the **Add** button.


Select a network location icon and enter the name of the location (e.g. Home). Click the **Next** button.



Select **Direct Connection** and click the **Next** button.



Select the LAN device, setup the IP address and click the **Next** button.



#### Obtain an IP address automatically

Select DHCP to use this option (automatic IP setting).

Click **Add Printer** and set up a printer according to the wizard.

When the printer has been added, click the **Refresh** button, select the newly added printer and then click the **Finish** button.




To not add a printer, click the Finish button.

When the network settings are complete, the **Do you** want to move to the newly added location now? message appears. Click the **Cancel** button.

An icon for the added location is created. The network settings have been completed.

If you select **OK**, the network settings for the added location are applied.





To add a new location, repeat the procedures from Step 3 above.


### **Using in Another Location**

By configuring the network settings (IP address, printer setting, etc.) for each location, you can immediately access the network in one click, without performing the network setting procedures regardless of your location.

- Click Start > All Programs > Samsung > Easy
  Network Manager > Easy Network Manager when
  connected to the Internet.
- 2 Select an icon that represents the corresponding location from the Saved Locations window and then click **Move**
- If the Internet connection is a wired LAN, you can immediately load the settings for the new location and the corresponding network connection information is displayed in the Current Location Information window.

To connect to a wireless LAN, select the **AP Setting** from the menu. The available APs are represented as icons. If you double-click an AP icon to connect to, the computer is connected to the AP through the wireless LAN and you are moved to the corresponding location.

Click the **AP Setting** menu item at the top of the screen and double-click one of the available APs.






- The closer to the PC icon at the bottom of the screen, the stronger the signal from the AP is, while the further from the icon, the weaker the signal strength is.
- If a network key is required, request the key from your network administrator.

# **Diagnosing the Network Status**

You can diagnose the network state and find solutions for why you cannot connect to the network.

- Launch Easy Network Manager.
- Select Diagnosis from the menu.



- The Network Connections window appears. Click **Start** to start the network diagnosis.
- When the diagnosis is complete, a device with a problem is marked by a **X** mark icon with a description of the problem at the bottom of the window.

# Connecting with a Modem (Optional)


The procedures to connect to the Internet via a phone connection are described below.



#### **Before You Start!**

- To connect to the Internet, you have to subscribe to an Internet connection service of an Internet service provider (ISP).
- A modem port is optional and provided for some models only.
- The actual color and appearance of the computer may differ from the pictures used in this guide.
- Connect the phone cable to the Modem port.

  Take care to not connect a digital phone line to the modem port.



Connect to the Internet according to the instructions of your Internet service provider (ISP).



If the Internet connection is terminated abnormally, the connection is not released and the corresponding cost can be accrued.

# Bluetooth (Optional)

Bluetooth is wireless communications technology that allows access to nearby devices such as another computer, a cell phone, printer, keyboard, mouse, etc. without a cable connection. Using Bluetooth, you can exchange files, connect to the Internet, and construct a private network as well as communicate with a keyboard, mouse, printer, etc. without a cable connection.



#### **Before You Start!**

- The Bluetooth supporting function is only available between devices (a computer, cell phone, PDA, printer, etc.) and the
  connection may be restricted according to the profile of the corresponding device.
- The Bluetooth function is optional and may not be supported depending on your model.
- Compatibility to devices without the authentication or logo of Bluetooth is not guaranteed.

### **Bluetooth Function**

File Transmission		You can exchange files between two Bluetooth devices. You can exchange files with another Bluetooth device such as another computer, cell phone, PDA, etc.
Network Access		You can connect to another Bluetooth-installed computer in the same way as an Ad-Hoc mode in wireless LAN and connect to the network via an AP or an Internet connection sharing server.
Network Access through a Phone Connection		You can connect to the network via a Bluetooth cell phone.
Data Sync (Synchronization)		You can synchronize PIMS data (Outlook E-mail address data) with Bluetooth devices such as a cell phone, PDA, another notebook computer, etc.
Electronic Business Card (Vcard) Exchange		You can exchange business cards with Bluetooth devices such as a cell phone, PDA, another notebook computer, etc.
Sound Output	9	You can output computer sound to another Bluetooth device or vice versa.
HID Connections	3	You can connect and use Bluetooth peripherals such as a keyboard, mouse, joystick, etc.



For more information about using the Bluetooth function, refer to the online help of the Bluetooth Device.

## **Using Bluetooth**

The procedures to exchange files between computers supporting Bluetooth and to use other Bluetooth devices are described below.

# Using Bluetooth Devices (Connecting Headset supporting Bluetooth)


As an example, the procedures to connect to a headset supporting Bluetooth will be described below. Searching for Bluetooth devices corresponds to Steps 1 to 4 and may be slightly different depending on the device.





If the the Bluetooth icon does not appear on the Taskbar, click Start > Control Panel > Hardware and Sound > Bluetooth Devices > Options and select the Show the Bluetooth icon in the notification area check box. Click OK.

If the Bluetooth Device window appears, click Add.



If the Add Bluetooth Device Wizard screen appears, select the **My device is set up and ready to be found** and click the **Next** button.




When the search is complete, all available Bluetooth devices are listed. Select the Headset from the list and click the **Next** button.





- A Bluetooth device is represented by the device type and name (Dedicated Bluetooth ID).
- To use the Bluetooth headset, Bluetooth Pairing Mode is required. For the procedures to set up Pairing Mode, refer to the Headset Manual.

5 Enter the PIN in the device PIN field and click the **Next** button.





For pairing, a PIN is required. Since a PIN is provided by the headset manufacturer, refer to the corresponding manual.


- If the Completing the Add Bluetooth Device Wizard window appears, click **Finish**.
- The stereo headset is connected and you can now use the Bluetooth headset normally.

  If you cannot hear sound from the headset, you have to check Playback Device setting. Click the Start > Control Panel > Hardware and Sound > Sound and make sure the default Playback Device is set to Bluetooth Headset.


# **Exchanging Files between Bluetooth Computers**

The procedures to exchange files between computers with Bluetooth capability are described below.

- Click **Browse**, select a Bluetooth device to send the file to and click the **Next** button in the Select Bluetooth Device window.



Select a computer to send the file to and click the **OK** button.



Enter a PIN in the Bluetooth PIN Code field and click the **Next** button.



The **Bluetooth PIN Code** is a password used for connecting two Bluetooth devices. The user just enters the same PIN Code (E.g. same numbers) on both Bluetooth devices to make the connection.

- Click **Browse**, specify a file to be sent and click **Next** button in the Select File to be Sent screen.
- When the PIN input window appears on the computer to receive the file, enter the PIN from Step 5.
- When the FTP file access privilege request for the file reception notification window appears, click the notification window. If the Select Access Permission window appears, click the **OK** button.

### **Usage Instructions**

- Generally, Bluetooth devices deliver stable performance while connected within a 3m(10 ft.) distance.
- For Bluetooth to operate smoothly, use the computer in an open environment with no walls or obstacles in the way.
- You can connect to only one Bluetooth device at a time for a phone connection, data syncing, electronic business card exchange, FAX transmission/reception, sound related functions, and serial port functions.
- It is recommended using only one Bluetooth device at a time as connecting multiple Bluetooth or other wireless devices at the same time may slow or destabilize the Bluetooth connection.
- Data communications via Bluetooth may be poor when the CPU load is at full capacity or there are insufficient system resources.
- The Bluetooth function of a Bluetooth PDA, mobile phone, mouse or keyboard may be turned off. To use them in connection with a Samsung computer supporting Bluetooth, you must check if the Bluetooth function of the device to connect to is turned on.
  - For the procedures on turning on the Bluetooth function of a device, refer to the relevant device manual.
- The services provided by Bluetooth devices may vary depending on their capabilities. For the services provided by the Bluetooth device, refer to the device manual.

# **Chapter 5.**

Using Applications
Introducing Programs Samsung Update Plus (Optional) Samsung Magic Doctor (Optional)
Reinstalling Software (Optional)

# Introducing Programs

Using the software supplied with the Samsung computer, you can easily use functions and troubleshoot problems. Try to use the software after learning about the basic use of the software. For detailed information, refer to the help section of the corresponding software.



#### **Before You Start!**

- Every software program may not be provided depending on your computer model.
- In addition, some pictures may differ from actual product depending on the computer model and software version.



#### **Multi Media Functions**

### CyberLink DVD Suite (Optional)



CyberLink DVD Suite is a program developed by CyberLink Corp., that provides multimedia functions such as playing and burning DVDs or CDs. For more information, refer to the online help of the software.

### CyberLink YouCam (Optional)



CyberLink YouCam is a program developed by CyberLink Corp., and enables taking still or moving images with the built-in camera of the PC and adding various effects. For more information, refer to the online help of the software.

#### **Management Functions**

#### Samsung Update Plus (Optional)



Samsung Update Plus is a software function that examines and updates the Samsung software and drivers installed on your Samsung computer to the most recent versions. 

117

#### McAfee SecurityCenter (Optional)



McAfee SecurityCenter is a program developed by McAfee INC. that detects and cures computer viruses and protects the PC from various threats on the Internet. For more information, refer to the online help of the software.

### Easy Network Manager (Optional)



Easy Network Manager is a program that enables you to easily configure the network settings.

You can configure the network settings for each location and you can also diagnose the network status. **103** 

## Easy Battery Manager (Optional)



Easy Battery Manager is a power management program that provides easy-to-use power management and power saving settings so that the battery usage time can be extended. 

137

#### Battery Life Extender (Optional)

The Battery Life Extender is a battery power management program that enables extending the battery life. 

139

#### Easy Display Manager (Optional)

Easy Display Manager is a program that displays the changed setting on the screen when a setting is changed by pressing the shortcut keys, and enables changing the display mode through the Display Settings window.



Example) The icon that appears when pressing the Fn + ↑ keys to change the screen brightness.

#### **Easy SpeedUP Manager (Optional)**

This program enables you to select operation mode when you need maximum system performance or lownoise/low power consumption with one-click. 

52

# Phoenix FailSafe (Optional)

Phoenix FailSafe is a program developed by Phoenix Technologies LTD, that enables PC users to protect and track their PC via the FailSafe website when their PC is lost or stolen.

For more information, please refer to the online help of the software or the FailSafe website.

### **Troubleshooting Functions**

SAMSUNG Magic Doctor (Optional)



SAMSUNG Magic Doctor is troubleshooting software provided by Samsung Computer for system diagnosis. and restoring the system.

The system diagnosis function enables users to diagnose system problems without assistance from others.

Samsung Recovery Solution (Optional)



Samsung Recovery Solution provides a Restore Function that enables you to easily restore your computer to a previous, normal state when a problem occurs with your computer, as well as a Backup Function that enables you to easily save your computer's current status and your data.

# Samsung Update Plus (Optional)

Samsung Update Plus is software that examines and updates the Samsung software and drivers installed on your Samsung computer to the optimal version.



#### **Before You Start!**

- To check for updates and update your computer using Samsung Update Plus, your computer must be connected to the Internet.
- The update search result may differ depending on your computer model.



Samsung Update Plus does not provide updates for applications installed after purchasing the computer.

#### To update the software and drivers

Select Start > All Programs > Samsung > Samsung Update Plus > Samsung Update Plus.




If this is the first time you are running the program, a window will appear asking you if you agree to the agreement in the window.

Click **Agree** to use this software.

If you click on **Check for updates**, new updates are searched for.



If there are available software or driver updates for your computer, the available updates will be listed. Select the required updates from the list and click **Install Update** to start the update. (The update list on the screen may differ depending on the computer model.)






#### Updates that must be installed separately.

If you select an update item that must be installed separately, a message appears informing you of this. Follow the instruction message to correctly install it.



#### Automatic update items display

By default, your computer is configured to automatically check for updates. If there is a new update available, this is notified in the notification area. Click the balloon help icon in the notification area. Here you will be able to find the latest available updates.



# Samsung Magic Doctor (Optional)

Magic Doctor is troubleshooting software provided by Samsung Computer. A user can diagnose system problems via one-click or by selecting diagnostic items.



#### **Before You Start!**

The screens used in this manual may differ from actual screens according to the program version.

### **Diagnosing the System**


Diagnosing the System is a function to check system connections and diagnose problems affecting to system operation and solve it.

- Click Start > All Programs > Samsung > Samsung Magic Doctor > Samsung Magic Doctor.
- Click on Diagnose the System to start diagnosing the system.



When the system diagnosis is completed, the diagnostic result appears.


If problems are found, click the **Fix** button to correct the problem. Samsung Magic Doctor starts the corrective operations.



## **Viewing My Computer Information**

You can view detailed information about your computer in Samsung Magic Doctor.

Click on the icon in the shape of a monitor at the bottom of the main program screen to view detailed information about the computer.



# Reinstalling Software (Optional)

You can reinstall software using the System Software Media, when a device driver or computer application is not working properly.



#### **Before You Start!**

- When software is not working properly, it is recommended removing the software using the Add or Remove Programs of the Control Panel and reinstalling the software using the System Software Media.
- The System Software Media is supplied as a CD or DVD depending on your computer model.
- Some model is not supplied System Software Media depending on your computer model.

### **Running the System Software Media**

The System Diagnosis function enables users to diagnose the system connectivity, any system problems and resolve these problems.

- Insert the System Software Media into the CD drive. If the Auto Play window appears, select Run SoftwareMedia..... in the Install or Run Program field.
- In the User Account Control window, click Allow.
- If you are not logged in with an administrator account, you have to enter an administrator password in the User Account Control window.

The **System Software Media** will launch.
Select an installation option to start the installation.



Standard Installation	If you select this option, programs not currently installed on the computer are listed.
Minimum Installation	If you select this option, programs are listed that need to be installed on the computer (drivers, Windows updates, etc.).  You can conveniently use this option, when you need to install essential programs only.
Custom Installation	If you select this option, you can select the programs to be installed.  You can conveniently use this option, when you need to install an individual driver or program that is causing a problem.

## **Installing Software**



As an example, the installation procedures for the **Standard Installation** options are described below.

Select Standard Installation in the System Software Media main screen.



2 If the **Start Standard Installation** window appears, click the **Yes** button.

The drivers and programs, which were installed in the computer when you purchased the computer, are installed again.

The Software installations was completed window appears.

If you click **Yes**, the computer is restarted.

# **Chapter 6.**

**Settings and Upgrade** 

**Using the Security Lock Port** 

141

comingo ana opgia	40
LCD Brightness Control	124
BIOS Setup	125
Entering the BIOS Setup	125
The BIOS Setup Screen	127
Setting a Boot Password	129
Changing the Boot Priority	131
Upgrading Memory	132
Battery	134
Installing/Removing the Battery	134
Charging the Battery	135
Measuring the Remaining Battery Charge	136
Extending the Battery Usage Time	137
	Entering the BIOS Setup The BIOS Setup Screen  Setting a Boot Password  Changing the Boot Priority  Upgrading Memory  Battery Installing/Removing the Battery Charging the Battery Measuring the Remaining Battery Charge

# LCD Brightness Control

You can adjust the LCD brightness in 8 levels.



#### **Before You Start!**

The LCD brightness is the brightest (Level 8) when the computer is running on AC power, and it becomes dimmer when running on battery power.

### **Controlling the Brightness Using the Keyboard**

Adjust the LCD brightness by pressing the **Fn** + 1 key or the **Fn** + 1 key.

The LCD brightness can change up to 8 levels and the brightness increases by 1 level when pressing the **Fn** + the level when the le



#### Maintaining the changed LCD brightness even after turning the computer on again

To maintain the LCD brightness set by using the brightness control keys or through the Power Options, follow the procedures below.

- 1. Turn the computer on and press the F2 key when the SAMSUNG logo appears on the screen to enter the BIOS Setup.
- 2. Select the Boot menu and set the Brightness Mode Control item to User Control.
- 3. Press the F10 key to save the settings and exit Setup.

#### Saving battery power consumption

Decrease the LCD brightness when the computer is running on battery power or select **Samsung Optimized** in Easy Battery Manager to save battery power consumption.

Easy Battery Manager is optional and may not be surpported depending on your model.

#### Defective LCD Pixels

An LCD panel may include less than 4 defective pixels due to a limit in the manufacturing process and this does not affect the computer performance. The computer's LCD panel may have the same or similar number of defective pixels as other manufacturer's notebook computers.



#### Instructions for Cleaning the LCD

Clean the LCD panel with a soft cloth lightly moistened with computer cleansing detergent moving in one direction. Cleaning the LCD panel with excessive force can damage the LCD.

# BIOS Setup

The BIOS Setup enables you to configure your computer hardware according to your needs.



#### **Before You Start!**


- Use the BIOS setup to define a boot password, change the booting priority, or add a new device.
   Since incorrect settings may cause your system to malfunction or crash, take care when configuring the BIOS.
- The functions of the BIOS setup are subject to change for product function enhancement purposes.



The BIOS Setup menus and items may differ depending on your computer model.

## **Entering the BIOS Setup**

- Turn the computer on.
- When the booting screen (SAMSUNG logo) appears, press the F2 key to enter the BIOS Setup.






Press the F12 key while the booting screen(SAMSUNG logo) appears, the system will try to boot from the network.

After a moment, the BIOS setup screen appears.

The items in the BIOS setup may differ depending on the product.



# The BIOS Setup Screen

	Phoe	nix SecureCo	re (tm) S	etup Uti	lity
Main	Advanced	Security	Boot	Exit	
System System SATA Po	Date o <b>rt</b> 1	[10:21:53] [07/30/200X] XXXXXXXX XXXXXXXX			Item Specific Help <tab>, <shift-tab>, or  <enter> selects field.</enter></shift-tab></tab>

Menu	Description
Main	Used to change the basic system and environment settings.
Advanced	Used to configure advanced functions on your computer for devices and chipsets.
Security	Used to configure security functions, including passwords.
Boot	Used to set the boot priority and other boot options
Exit	Used to exit the Setup either saving the changes or not.

# **System Setup Keys**

In the Setup, you have to use the keyboard.

F1	F1	Press to view the Setup Help.
Up & Down Keys	↑.	Press to move up and down.
F5/F6	F5 F6 🕸	Press to change the item value.
F9	<b>F9 ▼</b>	Press to load the default Setup settings.
ESC	Esc D	Press to return to a higher level menu or to move to the Exit menu.
Left & Right Keys		Press to move to another menu.
Enter	<b>~</b>	Press to select an item or to enter a sub menu.
F10	F10	Press to save the changes and exit Setup.



The keyboard image may differ from the actual keyboard.

# Setting a Boot Password

When setting a password, you have to enter a password to use the computer or enter the BIOS Setup.

By configuring a password, you can restrict system access to authorized users only and protect data and files saved on the computer.



#### **Before You Start!**


- Do not lose or forget your password.
- If you have forgotten your password, contact a Samsung service center. In this case, a service fee will be charged.

### **Setting a Supervisor Password**

A Supervisor Password is required to turn the computer on or to start the System Setup.

When setting a Supervisor Password, users other than a supervisor cannot use the computer.

- Select the **Security** menu in the BIOS Setup.
- In the **Set Supervisor Password** item, press < Enter>.



Enter a password, press **<Enter>**, re-enter the password for confirmation, and press **<Enter>** again. The password can be up to 8 alphanumeric characters. Special characters are not allowed.



When a message confirming the password configuration appears in the **Setup Notice** window, press **<Enter>**.

The supervisor password has been set.

The supervisor password is required to turn the computer on or to enter the BIOS Setup.

## **Setting a User Password**

Users can start the system with a user password, but cannot enter the System Setup. By doing this, you can prevent other users from entering Setup.

Before configuring a user password, a **supervisor password** must have been configured. Deactivating the supervisor password also deactivates the user password.

In the **Set User Password** item, press **<Enter>** and complete the procedures from Step 3 of Setting a Supervisor Password.

### **Setting Up a Boot Password**

To setup a boot password, the administrator password (**Set Supervisor Password**) should be set in advance. Set the **Password on boot** item to **Enabled**.

Once a boot password is set, you have to enter a password to boot up the computer.

# **Setting up a Hard Disk Drive Password** (Optional)

A supervisor password must be set using the Set Supervisor Password menu.

If you set a password for a hard disk drive, it cannot be accessed from another computer.

Press **<Enter>** in the **Set HDD Password** item and define a password as described in Step 3 of the Setting up the Supervisor Password.



The hard disk drive password setting function is not provided for some models.



#### Changing the hard disk drive password

For security purposes, you can only change a hard disk drive password after restarting the computer by pressing the computer **Power** button.

If you cannot change the hard disk drive password or the **HDD Password Frozen** message appears when entering the BIOS Setup and then selecting **Security** > **HDD Password**, press the **Power** button to turn the computer on again.


### **Deactivating the Password**

- Press <Enter> on the password to be deactivated.
  For example, to deactivate a supervisor password in the Set Supervisor Password item, press <Enter>.
- In the **Enter Current Password** item, enter the currently configured password and press **Enter**>.
- Leave the **Enter New Password** item field empty, and press **<Enter>**.
- Leave the **Confirm New Password** field empty, and press **<Enter>**.
- In the **Setup Notice** window, press **<Enter>**. The password is deactivated.


# Changing the Boot Priority

By default, the highest boot priority device is set to the CD-ROM/DVD drive. As an example, the procedures to change the highest boot priority device to the hard disk drive are described below.

- Select the **Boot** menu in the BIOS Setup.
- Press <Enter> on the Boot Device Priority item.



Press the down key (1) to move to the **AHCI HDD** itemand press the **F6** key to move up to the top item.



Press the **F10** key to save the settings and exit Setup.

The highest boot priority device is now set to the Hard Drive.

# Upgrading Memory

One or more memory modules are installed on the computer.

There are 2 memory slots and users can replace the installed memory or add new memory.



#### **Before You Start!**


- Replace or install new memory only after shutting the computer down completely. Do not replace or install memory when the computer is in Sleep mode.
- Disconnect main power plug and remove the battery before continuing.
- To utilize the dual channel feature, using memory modules with the same specifications (of the same capacity and from the same manufacturer) is recommended.
- Only use the same type of memory as specified in the Product Specification.

### **Adding a Memory Module**

Remove the screw on the memory compartment cover at the bottom of the computer using a screw driver.



Insert a new memory module into the memory slot at an angle of approximately 30 degrees aligning it to the angle of the memory slot.



Push the memory module down so that it is completely fixed. If the memory does not fit easily, push the memory module down while pulling the memory module latches outward.



Close the memory compartment cover and fasten the screw.



#### Removing a memory module

Pull the memory module latches outward. The memory module will pop up.

Remove the memory module out at an angle of 30 degrees.



# **Battery**

Please refer to the following instructions when running the computer on battery power without connecting the AC power.

A Lithium-Ion smart battery is supplied with this computer.



#### **Before You Start!**

Carefully read and follow the precautions printed on the battery before using the battery.



#### **Precautions**

Use only chargers specified in the User Manual.

Never heat the battery pack, put it near or in a fire or use at a temperature higher than 60°C, as this may cause fire.


Never cause a short circuit between the battery pack terminals or disassemble the battery pack.

Carefully read and follow the precautions printed on the battery and the safety instructions in the User Manual before using the battery.

Please refer to the system operation environment ( 186) of this manual and operate and store the battery at room temperature.

## **Installing/Removing the Battery**

- Shutdown the system, close the LCD panel and place the computer upside down on a flat surface.
- Pull the two battery latches **outwards**, then remove the battery.



To install the battery again, slide the battery into the system.

The battery latches move inwards and fix the battery automatically.





Check if the battery latch has been moved inwards.

# **Charging the Battery**

- Attach the battery and connect the AC adapter to the DC-in jack of the computer.

  The battery will then start charging.
- When charging is complete, the Charge LED turns green.

Status	Charge LED
Charging	Red
Charging complete	Green
AC adapter not connected	Off

## **Measuring the Remaining Battery Charge**

You can view the battery charge status by completing the following procedures.

### To use the shortcut key to view

Press the **Fn** + keys on the keyboard. The remaining battery charge (%) will displayed for a moment.

You can only view the charge status in this way when Easy Display Manager is installed on your computer.

### To view on the battery

Separate the battery and press the **PUSH** button inside the battery. The remaining battery charge (%) will be displayed.





#### **Battery Warning**

- You will hear an alarm when the remaining battery charge reaches below 10%.
  - In this case, connect the AC adapter or turn off the computer and install a fully charged battery.
- If the battery residual amount is 3~5%, the computer automatically shuts down after saving the data. The battery residual amount may vary depending on the computer model.

### **Battery Usage Time Information**

A battery is an expendable supply, so when using it over a long time, the capacity/battery life is shortened. If the battery life is reduced to under half of its initial time, we recommend purchasing a new battery.

For long periods of not using the battery, keep the battery after discharging it. This extends the battery life time.

## **Extending the Battery Usage Time**

### **Decreasing the LCD Brightness**

Press the **Fn** + [ ↓ ‡ ] keys on the keyboard to decrease the LCD brightness to extend the battery usage time.

## **Using Easy Battery Manager (Optional)**


Easy Battery Manager is a power management program that enables using the battery power efficiently. You can select an optimized power mode according to your requirements.



Easy Battery Manager is optional and may not be supported depending on your model.

- Click Start > Control Panel > Hardware and Sound > Power Options.

  Alternatively, right-click the power measuring device icon in the notification area of the taskbar and select Power Options.
- If the following screen appears, select one of the modes.



Samsung Optimized	This mode is appropriate for normal conditions. It maximizes the system performance when the computer is running on AC power while maximizing the battery usage time when the computer is running on battery power.
Multimedia	This mode is appropriate for a multimedia environment that requires maximum system performance. Therefore, the battery usage time may be reduced in this mode.



#### **Using the Easy Battery Manager power options**

To use the Easy Battery Manager power options after reinstalling Windows, you have to install the Easy Battery Manager manually using the system software media.

Since power options in Easy Battery Manager aim at maximizing the battery usage time, programs requiring high performance may slow down when using the battery.

In this case, it is recommended connecting the AC adapter or selecting Power Saver.


### **Extending the Battery Life (Optional)**

The Battery Life Extender is a battery power management program that enables extending the battery life. Users can change the settings depending on their requirements.



The Battery Life Extender is optional and may not be supplied depending on the model.

- ✓ Click Start > All Programs > Samsung > Battery Life Extender > Battery Life Extender.
- When the following screen appears, select a mode and click the **OK** button. You can use the battery in the selected mode.



Battery Normal Mode	This mode maintains 100% of the battery charge when using the computer on AC power. In this case, although the battery use time increases, the battery life is reduced.
Battery Life Extension Mode	This mode maintains 80% of the battery charge when using the computer on AC power. In this case, although the battery use time decreases, the battery life is extended.




Press the F2 key when the Samsung logo appears in the booting sequence to enter the BIOS Setup, select **Advanced > Battery Life Cycle Extension**, and set it to **Enable**. Then you can use the battery life cycle extension mode.

### **Using the Battery Calibration Function**

When charging/discharging the battery repeatedly for a short time only, the battery usage time may be reduced by the difference between the actual battery charge and the remaining charge display.

In this case, the actual battery charge and the remaining charge display will be the same by discharging the battery completely using the Battery Calibration function, and then recharging it again.

- Disconnect the AC power adapter after turning off the computer.
- Restart your computer and press the **F2** button when the Samsung logo appears, to start the BIOS Setup.
- Move to the **Boot > Smart Battery Calibration** item using the direction keys and press **<Enter>**.



Highlight Yes in the Battery Calibration Confirmation window and press <Enter>.

The Battery Calibration function is activated and the battery is forcefully discharged. To stop the operation, press the **<Esc>** button.

This operation requires 3~5 hours depending on the battery capacity and the remaining battery charge.



You can connect a Kensington lock to the Security Lock port to prevent your computer from being stolen when you have to use the computer in a public place.

To use this feature, you have to purchase the Kensington lock additionally. To use the Kensington lock, refer to the product manual.

Tie the Kensington lock cable to a fixed object and install the other end of the cable to the Security Lock port.



# **Chapter 7.**

# **Windows Media Center**

	Williadwa Madia deli	
- 11 11	About Package Contents and the Program Guide 14	
	Connecting and Setting Up Media Center	14
	Connecting Devices	14
	Media Center Setup	14
	Using Media Center	14
	Start Screen Layout	14
	Pictures + Videos	14
	Music	15
	TV + Movies	15

Windows Media Center is provided for some versions of Windows Vista only.

Therefore, this chapter is for models with Windows Media Center only.

# About Package Contents and the Program Guide

## **About the Package Contents**

The package contents of your Samsung computer may differ depending on the computer model.

A TV tuner card is not supplied with the product and is not essential for the Media Center.

However, you can only use the TV function of the Media Center when a TV tuner card has been installed.

### **About the Program Guide**

An electronic TV program guide, the Electronic Program Guide (EPG) is provided by the EPG provider and the contents of the EPG may differ from the actual TV program depending on programming changes by the EPG provider or broadcast station.



The contents of this manual are subject to change for product improvement purposes.

# Connecting and Setting Up Media Center

The basic usage of Media Center for Microsoft Windows Vista Home Premium is described below.



#### **Before You Start!**

This manual will describe procedures assuming that you are using Media Center with a mouse.

### **Connecting Devices**

#### Connecting to the Internet

To view the TV Guide or to move to Media Center sites in Media Center, you have to connect to the Internet. Connect the network (LAN) cable to the **LAN port** of the computer.



If the computer is not connected to the Internet, you cannot use the TV Guide (Channel Information) and the Online Spotlight functions.

### Connecting the TV antenna

To use the Media Center TV function, you have to connect the TV antenna to the TV tuner card.

If your computer has a built-in TV tuner card, connect the TV antenna cable to the TV Antenna Input port.



If you do not have an installed TV tuner card, you cannot use the TV function.

To use the TV function, purchase and install an additional TV tuner card.

### **Media Center Setup**

Connect all necessary devices and setup Media Center. You have to complete the settings to use Media Center.

- Turn the computer on.
- 2 Click Start > Windows Media Center or Start > All Programs > Windows Media Center.



If the following start screen appears, select the installation option.

Express Setup enables you to use the basic functions of Media Center when clicking **OK**. However, you cannot use TV and Internet related functions using Express Setup.

Custom Setup allows you to configure all settings including TV and Internet settings. If you click **OK**, the Setup Wizard starts.





To setup the TV or Internet after an Express Setup, select **Tasks > Settings > General > Windows Media Center Setup** in the Media Center start screen and setup the following items.


If you have selected Custom Setup, continue with the setup according to the Setup Wizard instructions.

If there are no installed TV tuner cards, the TV related setup steps will appear during the Media Center setup.

In addition, if the computer is not connected to the Internet, you cannot setup and use the TV Guide (Channel Information).

When the Media Center setup is complete, click **Finish**.

Now you can use the Media Center.





#### **Changing the Media Center settings**

You can change the settings by selecting **Tasks** > **Settings** in the Media Center start screen after completing the Configuration Wizard.

# Using Media Center

The descriptions of the Media Center start screen and basic functions will be given below.

### **Start Screen Layout**




#### **Before You Start!**

If you selected **Run Setup Later** in the Media Center start screen or did not complete the Setup Wizard, the Setup Wizard screen appears when launching Media Center.

If you complete the setup, the Media Center start screen appears.

Click Start > Windows Media Center or Start > All Programs > Windows Media Center.

#### Move to the Media Center Start Screen



Pictures + Videos	You can view pictures, images and video files.
Music	You can listen to music files, audio CDs and the radio.
TV + Movies	You can watch and record TV programs and play DVD titles.
Online Media	You can access all kinds of multimedia content over the internet.
Tasks	You can change the Media Center settings.
Navigation Arrow	If you move the mouse pointer over the arrow, you can navigate through the menu in the up, down, left and right directions.



The Menu and Play Control buttons appear for a moment only when moving the mouse pointer. The Media Player window size decreases if you perform another task after playing a media file.

### Pictures + Videos

In Pictures + Videos, you can view pictures and videos registered to the Media Center library.

In addition, you can also view files not registered to the library by registering them, as well as viewing files on a removable disk.

### Registering to the Library


The procedures to register files to the library are described below.

Launch Media Center, and select Pictures + Videos > Picture Library or Video Library.




When you run it for the first time, a LIBRARY SETUP window may appear. In this case, you can add files according to the instructions on the screen.

2 In the library menu, right-click and select **Library Setup**.



- If the Library Setup screen appears, select **Add** Folder to Watch.
- Specify the path for the folder according to the instructions on the screen.
- If the following screen appears, click **Finish**. You can view the newly added folder in the Picture Library or Video Library.



### **Viewing Pictures and Images**

The procedures to view pictures and images registered to the library are described below.



Picture and image files are saved in the Computer > Local Disk (C:) > Users > User Accounts > Picture Folder or Computer > Local Disk (C:) > Users > Public > Public Pictures folder

- Launch Media Center, and select **Pictures + Videos**.
- Select Picture Library.



When you run it for the first time, the **Setup Library** window may appear. In this case, click the **No** button.

Select a folder with picture files.



If you select a picture, the picture is displayed in full screen.

You can view another picture by using the Play Control buttons or the direction buttons on the keyboard.

To view pictures in a SlideShow, click on **Play SlideShow**.

Alternatively, select **Pictures + Videos > Play All**. Then the pictures in the registered folder are displayed in a random order.

#### **Viewing Videos**

The procedures to view videos registered to the library are described below.



Video files are saved in the Computer > Local Disk (C:) > Users > User Accounts > Video Folder or Computer > Local Disk (C:) > Users > Public > Public Video folder.

- Launch Media Center, and select **Pictures + Videos**.
- 2 Select Video Library.



When you run it for the first time, the **Setup Library** window may appear. In this case, click the **No** button.

Select a folder with video files.

If you select a video file, the video file is played.



# **Viewing Pictures and Videos Saved on Removable Media**

The procedures to view pictures, images and videos saved on removable media in Media Center are described below.

- Launch Media Center.
- 2 Insert a removable media with picture, image or video files.

Removable media refers to a CD, DVD, USB flash memory, memory card, etc.



To view pictures saved on a digital camera, connect the digital camera and the computer using a USB cable.

After a while, a window notifying you that new media has been found appears. Select **View Pictures** or **View Videos**.



- If the file list appears, select a file.
- 5 View the picture or video.

#### Music

In Music of Media Center, you can play music files or audio CDs. In addition, you can rip the tracks of an audio CD onto the computer and play them later individually or by using a playlist.

#### Playing an Audio CD

- Launch Media Center.
- Press the Eject button of the CD-ROM drive to open the CD tray and insert an audio CD. The tracks on the CD are played automatically.

#### Ripping an Audio CD

- Launch Media Center.
- 2 Insert an audio CD into the CD-ROM drive and play the CD.

3 Select **Copy CD** at the bottom left of the Music Player window.





When running the Rip CD function for the first time, the Ripping Options appear. Configure the ripping options according to the instructions on the screen, and complete the following procedures. From the second time the program is run, the setup options are omitted.

If the Rip CD window appears, click **Yes**.

Ripping a CD begins by showing rotating CD icon on the right side that indicates ripping a CD is in progress. When ripping is complete, the ripping CD complete message appears.



The ripped tracks are displayed in the **Music > Music Library** of Media Center and in the **Library** of Windows
Media Player. The ripped tracks are copied to **Start > Music** of the Desktop as album files.

To change the folder to save the ripped tracks to, launch Windows Media Player and right-click over the top taskbar and select **More Options > Rip Music > Rip music to this location** from the pop-up menu.

### **Playing Ripped Tracks**

- Launch Media Center, and select Music.
- 2 If you select **Music Library**, the album list appears including the ripped album.



Ripped music albums

- Select an album to be played and click **Play Album** in the left pane.
- The album is played.

### **Using Playlists**

You can easily create, manage and play a playlist with ripped music albums and music files downloaded from the Internet.

- Launch Media Center, and select Music > Music Library.
- You can search for a music file by selecting the album, artist, genre or song at the top.
  If you select Playlist > All Music, all registered music files are listed.
- Select the music files to be added to the playlist and click **Add to Queue** in the left pane.
- The + mark starts blinking at the bottom left of the Media Player window and disappears the selected music files are added to the queue.



**Media Player Window** 

- Select the Media Player window at the bottom left and click **View Queue**.
- Select **Save As Playlist**, enter a playlist name and select **Save**. If you have a remote control, you can enter a name using the numeric buttons on the remote control.



To play the saved playlist, select **Media Center > Music Library > Playlist**, select a playlist and click **Play**.



- If a music file appears in the Media Center even after the file has been deleted
  - If you deleted a music file, you must also manually delete the file from the Media Center playlist.
- Deleting a playlist from Media Center
   Select Media Center > Music Library > Playlist,
   select a saved playlist and click Delete. Then the
   selected playlist is deleted.

### **TV + Movies**



#### **Before You Start!**

The TV function is only available when a TV tuner card is installed on your computer.

#### TV + Movies Menus

Live TV	You can watch live TV programs.
Recorded TV	You can watch recorded TV programs.
Guide (TV Broadcast Program Guide - EPG)	You can view the TV program guide. You can watch or record live TV programs and reserve a recording.
Play DVD	The DVD title appears.
Search	You can search for a program by the title, keyword or genre.



#### What is a TV Program Guide - EPG?

An Electronic Program Guide (EPG) is a TV program guide. You can select a program and view detailed information on that program or easily reserve a recording. The guide information is updated by Media Center more than once a day.

#### **Watching TV**

- ▲ Launch Media Center and select **TV** + **Movies**.
- Select Live TV or Guide from the menu.
  - When Live TV is selected

A TV program is played immediately. Switch to the channel you want to start watching it.

When Guide is selected

When the Guide List is displayed, select a program currently being broadcast. The program on the selected channel is displayed.



Programs that are being broadcast are represented in white and programs that have been broadcast or will be broadcast are represented in blue.

#### Switching channels

- Select a channel from the Guide.
- Moving the mouse will display the play control buttons. Click the ch+ or ch- buttons to switch channels.



Using the play control buttons while watching TV Moving the mouse will display the play control buttons. Select Pause, Play, Fast Forward, Rewind or Skip according to your requirements.

#### **Recording a TV Program**

The procedures to record the current program and reserve a recording will be described below.

- Recording the current program
- Moving the mouse will display the play control buttons. When the play control buttons appear, click the **Record** button.

A red dot appears indicating that a recording is in progress and the recording begins.

- To stop the recording, right-click and select **Stop Recording** from the pop-up menu.

  Alternatively, move the mouse and double-click the **Record** button.
- Recording or reserving a recording in the Guide
- ✓ Launch the Media Center and select TV + Movies.
- Select Guide from the menu.

Move to a program to be recorded.


Right-click over a program to be recorded and select

Record. A red dot appears over the program list.



- If the selected program is scheduled to be broadcast later, the recording is reserved.
- Recording a series.

Right-click over a program to be recorded and select **Record Series**. The Series Recording Indicator appears.



TV recording, exit Media Center when leaving the computer. A reserved TV recording is conducted regardless of whether Media Center is executed or not.

### Watching a recorded program



Recorded files are saved in the Computer > Local Disk (C:) > Users > Common > Recorded TV folder.

- ▲ Launch Media Center and select TV + Movies.
- Select Recorded TV from the menu.
- 3 Select a program you want to watch in the following window.
- 4 Double-click the program list or right-click and select **Play**.

The selected recording is played.

### Playing a DVD

The procedures to watch a DVD title are described below.

- Launch Media Center.
- Press the Eject button of the DVD drive to **open** the tray and insert a DVD title.



If you insert a DVD title without starting Media Center, the Auto Play selection window appears.

Select Play DVD Video using Media Center and click OK.

After a moment, the DVD menu is displayed. It the DVD menu is not automatically displayed, select **Play DVD** in the start screen.



Select **Watch Movie** or **Play** from the DVD menu. The DVD title is played.

If you move the mouse, the Play Control buttons appear. Using the Play Control buttons, you can play the DVD from a particular point or stop playing the DVD.

#### **Online Media**

You can access more online content through Online Media.

Online Media is a service provided by content providers via the Media Center. You can enjoy all kinds of multimedia content such as movies, news, sports, etc. over the Internet.



- To use Online Media, your computer must be connected to the Internet.
- For problems encountered while using Online Media, contact the corresponding online service provider. Online Media content services are not the responsibility of the computer manufacturer.

# **Chapter 8.**

**Appendix** 

Reinstalling Windows Vista (Optional)	16
Using Samsung Recovery Solution (Optional)	16
Samsung Recovery Solution Functions	16
Using Samsung Recovery Solution	16
Q & A	17
Display Related	17
Sound Related	17
Modem Related	17
Wired Network (LAN) Related	17
Wireless Network (WLAN) Related	17
Game and Program Related	18
Bluetooth	18
Blu-Ray (Optional)	18
Other	18
Product Specifications	18

Glossary

Index

198

201

### Reinstalling Windows Vista (Optional)

You can reinstall Windows using the **System Recovery Media** for Windows Vista when Windows is no longer working properly. (For models supplied with a System Recovery Media.)

For models supplied with the Samsung Recovery Solution, you can reinstall Windows using the Samsung Recovery Solution.



#### **Before You Start!**

- A System Recovery Media may not be supplied depending on your computer model.
- If you cannot start Windows, or if you want to delete all existing data and reinstall Windows, install Windows according to the descriptions in [Reinstalling when Windows does not start] (see page 3 163).
- The manual describes procedures on the basis of Windows Vista Home Premium. Some pictures may differ from actual product.
- Since Windows Vista may be upgraded to increase performance, some of the installation procedures may differ depending on the Windows Vista version. This guide describes how to reinstall Windows on the basis of the latest version, Windows Vista SP1.



Reinstalling Windows may delete data (files and programs) saved on the hard disk drive. Make sure to backup all important data. Samsung Electronics shall not be held liable for any loss of data.

### Reinstalling in Windows

1


Insert the **System Recovery Media** into the DVD drive.

When the **AutoPlay** window appears, select **Run setup.exe** and click **Allow**.



- Since the installation step may differ depending on the Windows Vista version, continue the installation according to the following descriptions.
  - 3-1 If a window appears which allows you to select the operating system to install,

click Next. Step 4 follows.





The operating system name may differ depending on the Windows version.

 3-2 If the Select Windows Installation window appears (for Windows Vista SP1),

click **Install Now**. When the Select Update window appears, click on the relevant item.






If you select **Go online to get the latest updates for installation** in the Select Update window, the latest updates are installed and Step 4 follows. At this time, the computer must be connected to the Internet.

- If the User Agreement screen appears, select I accept the license terms and then click Next.
  - For Windows Vista SP1, the following window appears. In this case, select an installation option.

If you click **Custom**, Steps 5 to 12 are continued sequentially.

If you click **Upgrade**, Step 6 begins. After that, proceed to Step 11.





#### Custom

Select this option to **Reinstall Windows**. You have to reinstall all necessary device drivers and programs after the Custom installation. In addition, unnecessary folders and files may remain on the hard disk drives after the installation (e.g. C:\Windows.old, etc.).

#### Upgrade

Select this option to **Upgrade Windows** while maintaining current files, configurations and programs. Although you therefore do not need to reinstall the device drivers and programs, some programs may not work properly after the upgrade.

- When a window appears asking for the location to install the operating system to, select a disk drive partition and click the **Next** button.

Drive D includes an area to save the backup image used by Samsung Recovery Solution. Installing Windows to drive C is recommended.



When previous Windows installation files are in the selected partition, a message appears informing you that the files and folders will be moved to the Windows. old folder. Click the **OK** button.

The Windows installation continues.

The computer will restart 3 times during the installation. If the **Press any key to boot from CD or DVD...** message appears after a restart, do not press any button.

- The Windows user registration screen appears. Select the username and photo and click the Next button.
- Enter the **computer name**. The window in which you can select the Desktop background appears.

  Enter the contents and click the **Next** button.
- The Windows automatic protection settings window appears.
  Configure the setting according to your requirements.
- The **time and date settings** window appears. Click the **Next** button.
- The **Registration Complete** window appears. If you click the **Start** button, a computer specifications check begins.
- After a while, the Windows Desktop appears.

  When Windows is launched, install the device drivers and applications according to your requirements using the **System Software Media**.

# Reinstalling when Windows does not start

When Windows does not start, boot up with the System Recovery Media and from there you can reinstall Windows.

- Insert the **System Recovery Media** into the DVD drive and restart the computer.
- If the Press any key to boot from CD or DVD...
  message appears while booting, press any key on the keyboard.

Press any key to boot fron CD of DVD.... \_

- After a while, the Options windows such as Language, Time, Keyboard, etc. appear. Confirm the settings and click the **Next** button.
- Since the installation step may differ depending on the Windows Vista version, continue the installation according to the following descriptions.
  - 4-1 If a window appears which allows you to select the operating system to install,

click Next. Step 5 appears.



The operating system name may differ depending on the Windows version.

 4-2 If the Select Windows Installation window appears (for Windows Vista SP1).

Click Install Now.

- If the User Agreement screen appears, select I accept the license terms and then click Next.
  - For Windows Vista SP1, a window where you can select an installation option appears.
     In this case, click Custom.
- When a window appears asking for the location to install the operating system to, select the partition of the disk drive and then click the **Next** button.



Drive D includes an area to save the backup image used by Samsung Recovery Solution. Installing Windows to drive C is recommended.



- A If you click **Drive Options (Advanced)**, you can delete, format, create or expand a partition. Click on a function and proceed according to the instructions on the screen.
- When previous Windows installation files are in the selected partition, a message appears informing you that the files and folders will be moved to the Windows.old folder. Click the OK button.
- The subsequent steps are the same as those for Reinstalling in Windows. 162

# Using Samsung Recovery Solution (Optional)

Samsung Recovery Solution provides a **Restore Function** that enables you to easily restore your computer to a previous, normal state when a problem occurs with your computer, as well as a **Backup Function** that enables you to easily save your computer's current status and your data.




- Samsung Recovery Solution may not be provided or the version may differ depending on your computer model and the usage
  procedures may differ depending on the version. The screen images in this document may differ from actual product.
- For models with an SSD (Solid State Disk), Samsung Recovery Solution is not provided.

### Samsung Recovery Solution Functions


#### O Restore Function

Using this function, you can easily restore your computer to a previous, normal state without using the System Recovery Media or the Windows Installation CD, when your computer is no longer working properly or fails to boot up due to a problem. If you have backed up data, you can restore the backup data.



#### O Backup Function

You can backup the entire C drive or all your data to **another hard disk drive** or **DVD**. You can restore the backed up drive or data using the Restore function.



### **Using Samsung Recovery Solution**

Not only can you use Samsung Recovery Solution when Windows is running, but also when you are unable to boot up into Windows. Let's learn how to use Samsung Recovery Solution.

#### **Initial Status Backup**

If you turn your computer on for the first time, the Initial Status Backup function is performed after registering Windows. This function saves an image of the Initial Status of the C drive to a secure location so that users can restore the computer to the Initial Status using the Complete Restore function. An Initial Status Backup is only performed once immediately after the computer is purchased.

- If you turn the power on for the first time, the Register Windows screen appears. If you register Windows according to the instructions on the screen, the computer will be restarted.
- When the computer has been restarted, the User Registration Complete message appears. Click **OK**. The computer will restart.

- The Initial Status Backup screen appears.

  To resize the C and D drives, click Advanced and partition the disk accordingly. Adjust the partition size using the slide bar and then click Next.
  - The partition disk function is only available when the computer is turned on for the first time and will not be available afterwards. Once you have completed the partitions, you cannot resize the partitions. Therefore partition the disk carefully.
- The Initial Status Backup is performed to backup the initial status of the C drive to a secure location. This backup image is used for the **Complete Restore** function that restores your computer to the initial status when the computer is not working properly.
- When the Initial Status Backup is complete, restart Windows.

#### **Quick Restore**

Quick Restore enables you to easily restore your computer to a previous, normal state when a problem occurs with your computer. Quick Restore provides Basic Restore and Complete Restore (Computer Initial Status Restore) options.

- When Windows is running:

Click Start > All Programs > Samsung >

Samsung Recovery Solution > Samsung

Recovery Solution.

#### - When Windows does not start:

Turn the computer on and press the **F4** key when the boot screen (SAMSUNG logo) appears. After a moment, the computer boots up in Restoration mode and the Samsung Recovery Solution screen appears.



The touch screen function is not supported in this mode even if your model supports a touch screen. In this mode, please use the touchpad or mouse instead of the touch screen.

- 2 If the Samsung Recovery Solution program is launched for the first time after purchasing the computer, the license agreement screen appears before the restoration is started. Read the agreement and click **Agree** to continue.
- If the initial menu screen appears, click **Restore**.



If you click **Select by Symptom**, the Select by Symptom menu appears. If you select a symptom, a recommended restoration option will blink. Click the restoration option to continue.

- Select either **Basic Restore** or **Complete Restore** from the Restore menu.
  - A Basic Restore restores the major Windows files only while maintaining the user configuration and data on the C drive in a short time.
  - A **Complete Restore** deletes the entire C drive and then restores the contents of the C drive.



Run Complete Restore if the computer does not work even after Basic Restore has been completed.

4-1 If you have selected Basic Restore:

In the Basic Restore screen, click the **Next** button. The system will be restarted.

4-2 If you have selected Complete Restore:

In the restoration point selection screen, select the restoration point described as 'Computer Initial Status' and click the **Next** button. The system will be restarted.

- Since a Complete Restore deletes all user data as well as additionally installed programs, please backup your important data first using the Data Backup function, before running Complete Restore.
- The computer boots up into restoration mode and the restoration progress message appears. If you click **OK**, the restoration begins. The restoration may take some time, please wait for a moment.
- When the 'Restart the System' message appears after the restoration is complete, click **OK** to restart the system.
- Make sure that the power cord is connected while the restoration is in process. The first time the computer boots up after a Complete Restore has been performed, the speed of the boot process may be slowed down due to the system optimization process. At this time, do not shut the computer down by force.

#### **User Complete Backup/Restore**

A **Complete Backup** saves the complete image of the C drive onto another drive or DVD. A **Complete Restore** restores the image file saved by the Complete Backup onto the C drive. This guide describes the Complete Backup and Complete Restore procedures on the basis of backing up and restoring by using DVD.

#### Complete Backup



If you run Complete Backup using a DVD, you can restore the computer even when a problem occurs with the hard disk or when the restoration area is removed.


Click Start > All Programs > Samsung > Samsung Recovery Solution > Samsung Recovery Solution.



When you cannot start Windows, turn the computer on and press the F4 key in the boot screen to enter restoration mode.

- When the initial menu screen appears, click Backup.
- Click Complete Backup in the backup menu.

Enter a description for the backup regarding the current computer status in the Description field so that you can easily recognize it later, and specify the Save Path. If your computer has a DVD-Writer, you can specify the DVD drive as the Save Path.



If you click the **Next** button, the system restarts in restoration mode and the **Complete Backup** begins. If you have selected the DVD drive as the Save Path, the "Enter a blank DVD" message appears. Insert a blank DVD and click the **OK** button.



Samsung Recovery Solution supports DVD+R, DVD-R, DVD+RW, and DVD-RW, but does not support CD-R, CD-RW, DVD-RAM, DVD-DL (Dual Layer), HD-DVD, and Blu-Ray.

- The Complete Backup begins. If multiple DVDs are required, the expected number of DVDs is displayed in the progress screen. Whenever burning a DVD is completed, the "Insert the next DVD" message will appear. Continue the backup according to the instructions.
- When the 'Restart the System' message appears after the backup is complete, click **OK** to restart the system.

#### **O** Complete Restore

- When backing up onto DVD
  - Turn the computer on and insert the backup DVD into the DVD drive.
    - If there are multiple backup DVDs, insert the first DVD.
    - When backing up to another drive Proceed to Step 2.
- Click Start > All Programs > Samsung > Samsung Recovery Solution > Samsung Recovery Solution.



When you cannot start Windows, turn the computer on and press the F4 key in the boot screen to enter restoration mode.

- When the initial menu screen appears, click **Restore** and then click **Complete Restore**.
- Select a **Complete Backup** restoration point in the restoration point selection screen and click the **Next** button. The system is restarted.
- The restoration progress message appears after the computer boots up in restoration mode. If you click **OK**, the restoration begins.



If multiple DVDs have been used for a Complete Backup, whenever burning a DVD is completed, the "Insert the next DVD" message will appear.

When the 'Restart the System' message appears after the restoration is complete, click **OK** to restart the system. The Complete Restore has been completed.

#### **User Data Backup/Restore**

**Data Backup** enables you to save specific files or folders onto another drive or DVD. **Data Restore** enables you to restore data using the data saved by a Data Backup when data is lost. This guide describes the Backup and Restore procedures on the basis of backing up and restoring by using DVD.

#### O Data Backup

Click Start > All Programs > Samsung > Samsung Recovery Solution > Samsung Recovery Solution.



When you cannot start Windows, turn the computer on and press the F4 key in the boot screen to enter restoration mode.

- When the initial menu screen appears, click **Backup** and then click **Data Backup**.
- In the data selection screen, select either Basic Selection or Select from all, select a folder or file to be backed up, and then click the Next button.
- Enter a description for the backup in the **Description** field so that you can easily recognize it later and specify the **Save Path**. If your computer has a DVD-Writer, you can specify the DVD drive as the Save Path.



If you have specified a hard disk drive or a removable disk as the Save Path, the **SamsungRecovery**\ **SamsungData** folder is created on the corresponding drive (e.g. D:\) and the data is saved to the folder. Take care to not delete the folder by mistake or on purpose.

- If you click the **Next** button, the Data Backup begins. If you have selected the DVD drive as the Save Path, the "Enter a blank DVD" message appears. Insert a blank DVD and click the **OK** button.
- The "Backup is completed" message appears.

#### O Data Restore

- When backing up onto DVD
   Turn the computer on and insert the backup DVD into the DVD drive.
  - When backing up to another drive
     Proceed to Step 2.
- Click Start > All Programs > Samsung > Samsung Recovery Solution > Samsung Recovery Solution.



When you cannot start Windows, turn the computer on and press the F4 key in the boot screen to enter restoration mode.

- When the initial menu screen appears, click **Restore** and then click **Data Restore**.
- Select a backup item to be restored in the backup list and click the **Next** button.
- Select a folder for the restoration and click the **Next** button. Data Restore begins.
- When Data Restore is completed, check if the data has been restored to the specified folder.

# Q & A

This section provides information on possible problems, solutions and other references for using the system.

### **Display Related**

The LCD screen is too dark or too bright.

**A** Turn the LCD backlight on or adjust the LCD brightness.

Press **Fn** + to turn the LCD backlight on or press **Fn** + or **Fn** + to adjust the LCD brightness.

The screensaver is activated while Media Player is playing a movie or video clip.

A Unselect Library > More Options > Player > Allow screen saver during playback in the Media Player.

In the following cases, the screen blinks or there is noise for a short time.

- Click the Graphics Related tab, Change Resolution, Change Display Device, Remove the AC Adapter, Restart the System, Change Power Scheme.
- A This may happen while the video driver is examining the connected device. While the detection process is busy, any connected display devices may blink or some noise may occur.

When I connect a projector, and change the settings to display the screen image on both the LCD and the projector by pressing the Fn+ [4], the screen is not displayed properly.

A Press the **Fn** + [\*4] keys again.

If the problem continues even after pressing the key combination, this is because the current resolution is too high and is not supported by the projector. In this case, change the resolution to 1024x768 pixels.

When I connect a projector, the taskbar at the bottom of the screen is not displayed on the projector.

A This occurs because a WXGA LCD supports a resolution of 1280×800 pixels but the resolution is not supported by the projector. In this case, change the resolution to 1024x768 pixels (recommended).

- The shortcut icons are not displayed on the screen even if I press the shortcut key.
- A The shortcut icons only appear when the Easy Display Manager program is installed.
- I have connected a monitor (or projector) to the computer, but the colors on the monitor are abnormally displayed.
- A Check if the monitor and computer are properly connected with the signal cable and reconnect the cable if necessary.
- I am trying to view the screen through a TV by connecting it through the HDMI port, but the edge of the screen is not displayed.
- A It is recommended using a notebook computer screen or monitor for documents and Internet pages. Although connecting via the HDMI port is recommended when watching video, it may be inappropriate for displaying documents and Internet pages because most TVs that support HDMI fail to display the edge of the screen or the characters on the screen properly.

- I cannot configure the Image Sharpness in the NVIDIA Control Panel of [NVIDIA Graphics].
- A The NVIDIA Control Panel >Adjust desktop Color Settings > Image Sharpening item is set to None and will not be configurable. This is normal. This function is only available for old graphic chipsets.

#### **Sound Related**

# How can I configure the sound for video or audio chatting?

- A Configuring the Realtek HD Audio Manager
  - 1) Select Control Panel -> Realtek HD Audio Manager.
  - 2) Select the Mic tab.
  - Select the Suppress noise and the Remove sound echo items and click the **OK** button.

When using the Remove sound echo option, select the **Play Device-> Speaker -> Level** tab and set the Microphone to Mute.

# I cannot hear my voice with the internal microphone.

A This is because the sound from the internal

microphone is removed so that the sound is not delivered to the speaker and causes feedback from the internal microphone. However, you can record the sound from the microphone normally.

When using an external microphone, select the Play Device-> Speaker -> Level tab and deselect Mute for the Microphone. Then you can listen to the sound from the external microphone through the speakers.

- Sound is recorded abnormally when I select the Remove sound echo option, connect an external microphone, select the Play Device-> Speaker -> Level tab and then deselect Mute for the Microphone.
- A This occurs because the algorithm used to remove the echo sound regards some of the sound as an echo and removes this, as the recording is done by playing the sound from the external microphone.

  After selecting the Remove sound echo option, please select the Play Device-> Speaker -> Level tab and select Mute for the Microphone for a normal recording.

#### **Modem Related**

# QI cannot hear the modem

- **A1** Check if the phone line is properly connected to the modem.
- **A2** Check if the modem driver is properly installed.
- Click Start > Control Panel > System and Maintenance > Device Manager > Modem and then check if the model is not marked with a yellow exclamation mark. If it is marked with an exclamation mark, it means that the modem driver is not properly installed. In this case, remove the installed driver and install the driver again.
- If the modem is not marked with a yellow exclamation mark, double-click the installed modem and select Diagnosis tab > Query modem to diagnose the modem. If there is no reaction to the command, it means the modem is out or order. In this case, restart the system or reinstall the modem driver and then diagnose the modem again. (Close all applications using the modem before diagnosing the modem.)

# When you are unable to make a call when using a switchboard

A In general, the dial tone of a switchboard or a digital phone switching system is not continuous unlike that of a PSTN line. Therefore, the modem may not make a phone call as it misreads the dial tone as a busy tone. In this case, perform the following.

#### O Use the AT Command

Add the ATX3 command for initialization.

Alternatively, enter the ATX3 command first before make a phone call.

The modem will not check the dial tone before making a phone call.

- Configuring the Model in the Control Panel
  - Click Start > Control Panel > Hardware and Sound.
  - 2 Click on Phone and Modem Options.
  - 3 In the **Modem** tab, select an installed modem and click **Properties**.
  - In the Modem tab of the Modem Properties window, unselect the Make a phone call after waiting for a dial tone option.
  - **3** When the settings are complete, click the **OK** button.

If you cannot make a phone call starting with a 0, such as 01432, 01421, 01433, etc., this is because the private switching system is set to block long distance calls. Ask your switching system administrator.

# When using the modem overseas

- **A1** Check if the country setting of the modem is set to the current country.
  - Since each country has slightly different telecommunication values, if the location is not set to the corresponding country, the modem may fail to make a phone call.
- Click Start > Control Panel > Hardware and Sound.
- **2** Click on **Phone and Modem Options**.
- 1 In the Dialing Rules tab, click Edit.
- In the General tab of the Edit Location window, set the Country/Region to your current country, enter the region code and then click the OK button.
- **A2** Since the shape of the phone line connector may differ depending on the country you are in, you may have to buy a phone line connector to make a phone call from that country.

# How can I receive a FAX in Sleep mode (Standby Mode)?

- A To receive a FAX when the computer is in Sleep Mode (Standby Mode), the computer must be configured as follows.
  - The FAX program must be configured so that it receives FAXES automatically referring to the FAX program manual.
- Click Start > Control Panel > Hardware and Sound.
- **②** Click on **Phone and Modem Options**.
- In the **Modem** tab, select an installed modem and click Properties.
- In the Power Management tab of the Modem Properties window, select the Wake up the computer with this device option and click the OK button.

(If the Power Management tab does not appear, select Change Settings in the General tab.)

When the modem is configured as above, and a FAX arrives, the computer wakes up from Sleep Mode and receives the FAX.

### Wired Network (LAN) Related

# The <Wake On LAN> function

- A1 <Wake On LAN> is a function that activates the system from Sleep mode when a signal (such as a ping or magic packet command) arrives over the network (wired LAN).
- Using the <Wake On LAN> Function
- Click Start > Control Panel > Network and Internet > Network and Sharing Center > Manage Network Connections.
- **2** Right-click on the Local Area Connection and select Properties.
- © Click Configure > Power Management tab. Select Allow this device to bring the computer out of standby, then click OK. Restart the system.
- If the system wake up from Sleep mode even though there is no received signal, use the system after disabling the <Wake On LAN> function.
- The LAN LED may not be turned off if System is shutdown without disabling the WOL (Wake on LAN) option.
- Connecting a wired LAN while using a wireless LAN may not activate the <Wake On LAN> function. Set the Wireless LAN to **Disable** to use the <Wake On LAN> function.
- Click Start > Control Panel > Network and Internet > Network and Sharing Center > Manage Network Connections.
- Right-click on the Wireless Network Connections and select **Disable**.

- When I am connected to a 100Mbps/1Gbps wired LAN and the computer exits Sleep/hibernation mode, a message appears informing you of a connection to a 10Mbps/100Mbps wired LAN.
- A When the computer exits standby/hibernate mode, restoring the network takes about 3 seconds.
   When the network is restored, it operates at 100Mbps/1Gbps.

### Wireless Network (WLAN) Related

# I cannot find an AP.

**A** Verify whether the Wireless LAN LED is on. If it is turned off, turn it on by pressing the Wireless LAN On/Off button ( $\mathbf{Fn} + \mathbf{f}^{g} \mathbf{y}$ ).

The Wireless LAN device is operating properly, but I cannot connect to the Internet or to another computer.

This is due to an incorrect configuration, or a configuration error. Check the following:

- **A1** When connecting to a wireless Ad-Hoc network, check if the network name (SSID) is the same.
- **A2** If a network key (encryption key) is used, the AP (Access Point) and wireless Ad-Hoc network keys must be the same.
  - The AP network key can be configured using an AP management program. For more detailed information, ask your network administrator or product provider.
- A3 Check that the device driver is installed properly. If the driver is not properly installed, you will find a yellow exclamation mark on the network icon by clicking Start > Control Panel > System and Maintenance > Device Manager > Network Adapter.

# The signal strength is excellent, but I cannot connect to the network.

Even if the signal strength is excellent, the network connection may not operate properly if the TCP/IP properties are not properly configured, or the network key (encryption key) is incorrect.

A Check that the TCP/IP properties are configured properly. When connecting to an AP, right-click the Network Connections icon on the taskbar and select Network and Sharing Center. If you click the View Status next to a connected wireless network device and then click the Detail button, you can view the IP information. If the IP is not allocated properly, the IP address will be displayed as follows (e.g. 169.254.xxx.xxx).

If the network does not provide DHCP, you have to specify the correct IP address by asking your network administrator.

Even if the network provides DHCP, the server may not allocate an IP address to the client properly, and the client station cannot connect to the network

# I cannot connect to the AP.

#### O Check the Computer Settings

A1 Select Start > All Programs > Accessories > Windows Mobile Center and check the wireless device status.

#### • When it is represented as Disconnected This means the computer is not connected to the AP. Check the status of the AP, referring to the descriptions of the Checking the SP Settings section below. Check the encryption key configured in the AP and retry to the connection.

- When it is represented as Connected, but you cannot connect to the Internet
   This means the computer is connected to the AP, but the AP or external network connected with the AP may have a problem.
- When the 'There is no wireless LAN adapter' message appears or there is no wireless LAN icon

This means the wireless LAN device is set to **Do Not Use** or the device is not recognized.

Check if the wireless device is properly recognized in the Device Manager window. If the device is set to **Do Not Use**, right-click and select **Use** from the pop-up menu.

A2 Verify whether the same network key (encryption key) has been entered for both the AP and the computer. The network key is an encryption key for encrypting the data transmitted between the AP and the computer. It is recommended setting the network key manually.

#### O Check the AP Settings

For the AP settings, refer to the User Guide provided by the AP manufacturer.

- A3 Verify whether the environment is suitable for using a wireless LAN. The use of a wireless LAN may be restricted according to the environment and distance. Obstacles such as walls or doors affect the use of a wireless LAN. Install the AP in a high and open space, 50cm from the wall and far removed from any other radio signal sources.
- **A4** Verify whether the AP is operating properly.
- When the AP is not operating normally, turn off the AP, wait a short while, and turn it on again.
- Verify whether the AP's firmware is the most recent version. (Contact the AP manufacturer or the place where you purchased the AP for details of the AP firmware.)
- **A5** Verify whether the AP has been properly connected to the network. Verify whether the network is operating normally by connecting the wired network cable, which has been connected to the AP, to your computer.
- A6 Check the network key settings (encryption key) again. When automatic code conversion (a passphrase function) has been selected and data communication is not functioning even with a normal wireless connection, it is recommended entering the network key (encryption key) manually.
- A7 Check the AP settings as follows. (The following is recommended for a standard environment and thus may differ according to the specific wireless network environment.)

- When several APs are present simultaneously, check the channel settings for each AP. When different APs are using nearby channels, interference may occur between the electronic waves. Set the AP channels further apart from each other. (Ex: Ch1, Ch5, Ch9, Ch13)
- When an AP's SSID (Service Set ID) option is set to "Hide", you cannot search for that AP on the computer. We recommend unselecting the "Hide" option for the AP. The SSID is a name used for distinguishing one wireless LAN from another wireless LAN.
- It is recommended using Long Preamble. Preamble is a signal for data transmission synchronization.
   Short Preamble may be supported by some types of APs but may cause compatibility problems.
- It is recommended using a static IP.
- Since static channel selection is more reliable than auto channel selection, it is recommended using a static channel.

# I cannot connect to a computer connected to the Ad-Hoc network.

- **A1** Check the security settings and network name of the wireless Ad-Hoc network.
- **A2** Check the TCP/IP settings of the computers connected to the wireless Ad-Hoc network. The IP addresses of the computers to be connected to a wireless Ad-Hoc network must be set to the same sub-network address.
- For example, if the TCP/IP setting is configured to a fixed IP address, select Use the following IP address in the TCP/IP Properties of the wireless adapter, configure the items as follows and try again.
  - IP: 10.0.0.1~10.0.0.254, Subnet Mask: 255.255.255.0.
  - It is recommended using a fixed IP address for wireless Ad-Hoc network connections.
- **A3** You have to register the IP address allocated for the wireless adapter as a 'Trusted IP' in McAfee SecurityCenter.
- Click McAfee SecurityCenter > Advanced menu
   Configure > Internet and Network > Advanced
   Trusted and Banned IPs, and register the
   IP address or IP address range as a Trusted IP address.

- During the wireless Ad-Hoc network operation, the AP (Access Point) is intermittently not found.
- A This problem occurs intermittently during the wireless Ad-Hoc network operation. Even if this problem occurs, the wireless Ad-Hoc network operation is working properly and is not affected. Click Refresh to update the AP list.
- I have set the same IP address for both the wireless and wired connections, but they do not work properly.
- A You cannot use wireless and wired connections using the same IP address. To sequentially use both the wired and wireless connections with the same IP address, you need to set the currently not needed connection to Do Not Use in the Network Connections of the Control Panel.

- The wireless LAN does not work properly when there is a device operating on an adjacent frequency in the vicinity of the product.
- A1 Channel interference may occur when a wireless video transceiver or a microwave oven is being used. If you experience channel interference from other equipment, we recommended changing the channel for connecting to the AP. For more information about AP settings, refer to the User Manual supplied by the AP manufacturer.
- **A2** Since IEEE802.11g equipment operates in hybrid mode when there is active IEEE802.11b equipment, the data rate may be degraded.

## **Game and Program Related**

Windows Vista may not provide some functions properly when performing some applications especially games, or may cause a problem due to a device driver compatibility issue. For the latest device drivers and bug fixes, please refer to the respective company's website.

# A 3D game does not work, or some functions are not working.

A Change the graphics settings of the game to '2D' or 'Software Renderer', then run the program again.

# The game is not displayed smoothly on the screen.

A For 3D games, the texture data for the 3D screen display is saved to the system memory.

If there is insufficient system memory, the data is saved to the hard disk drive and loaded to memory when required. This operation may temporarily stop displaying the picture on the screen.

In this case, lower the game resolution or the screen settings.

# The picture on the screen is displayed as a broken image for some games.

A part of the picture on the screen may be broken when playing some games that require a high-specification graphics card.

In this case, set the 3D function setting for the game to a lower value or set the game resolution to a lower value.

## **Bluetooth**

# When no headset is found or cannot be connected

- A1 If the headset is already connected to another device, you will not be able to find the headset and cannot connect to the headset even if the headset is found. Disconnect the connection to the other device and then start the search again.
- **A2** If the headset is connected to a power adapter, you cannot make a Bluetooth connection.

  Disconnect the power adapter and then retry.
- **A3** In general, a Bluetooth headset has 2 operating modes, On/Off mode and Pairing mode.

To connect the headset to another Bluetooth device such as a PC or cell phone, the headset must be in Pairing mode.

Switch the headset to Pairing mode and then retry the search operation.

In general, the headset in Pairing mode automatically returns to On/Off mode after a certain period of time.

# There is no sound or sound is intermittently interrupted after connecting a headset

- **A1** If your headset is a **mono headset**, check if a mono headset connection has been made. In this case, to resolve the problem, complete the procedures below.
- Ouble-click over the Bluetooth icon on the Taskbar, select the Audio tab and check the connection status of the Bluetooth Hands-Free Audio for the headset in the connected device list. If it is not connected, right click over the device and select Connect from the pop-up menu.
- Right-click over the Speaker icon on the Taskbar, select Playback Devices, and make sure that the Bluetooth Hands-free Audio is enabled. If not, right-click over Bluetooth Hands-free Audio and select Set as Default Device.

**A2** If your head set is a **stereo headset**, you have to check if the headset is connected as a stereo headset.

To resolve the problem, complete the procedures below.

- Double-click the Bluetooth icon on the Taskbar, select the Audio tab and check the connection status of the Bluetooth Stereo Audio that corresponds to the corresponding headset in the connected device list. If it is not connected, rightclick over the device and select Connect from the pop-up menu.
- Right-click over the Speaker icon on the Taskbar, select Playback Devices, and make sure that the Bluetooth Hands-free Audio is enabled. If not, right-click over Bluetooth Hands-free Audio and select Set as Default Device.



After changing the Bluetooth or sound settings, you must exit and re-run the audio/video player program (such as Windows Media Player) to apply the changed settings.

# Blu-Ray (Optional)

# Is it compatible with the existing CD/DVD formats?

**A** All Burning, Playback and Authoring functions are supported for the CD/DVD formats.

# Can I play an HD-DVD title?

A Since HD-DVD and Blu-Ray disk are different, HD-DVD titles are not supported.

# Which functions for the Blu-ray disk are supported?

A All Burning, Playback and Authoring functions are supported for Blu-ray disks. Supporting function of Blu-Ray ODD may differ depending on the models.

# Can I burn a Blu-Ray disk using a general CD-RW or DVD-RW drive?

**A** A general CD-RW or DVD-RW drive does not support burning the Blu-Ray format.

# Can I burn a Blu-Ray disk using the CyberLink DVD Suite (CDS)?

A Although the CyberLink DVD Suite supports burning the CD and DVD formats, it does not support burning the Blu-Ray format.

# (Only for BD-RE) Can I save 25GB data onto the each side of a Blu-Ray disk?

A The current Blu-Ray disk standard does not support double sided recording. Currently, you can save data onto a single side only. You can save 25GB data onto a single layer disk, and save 50GB onto a dual layer disk. (A dual layer disk consists of two layers.)

## Other

The User Controls window appears when installing or running a program in Windows Vista.

A In this case, click **Allow** (or **OK**) to install or run the program. However, if you do not have an administrator account, you have to enter the administrator password in the User Controls window and then click **Allow** (or **OK**). If no administrator password is set you can click **Allow** (or **OK**) without entering a password.

# **Product Specifications**

The system specifications may differ depending on the derived models. For detailed system specifications, refer to the product catalogue.

CPU (Optional)	Intel Core2 Duo / Pentium / Celeron Processor
Main Memory (Optional)	Memory type: DDR2 SODIMM
Main Chipset (Optional)	Intel GL40/PM45 + ICH9M
Hard Disk Drive (Optional)	9.5mmH SATA HDD
Optical Disk Drive (Optional)	Super Multi Dual Layer, Super Multi Dual Layer(LS) (Optional), BD-ROM (Optional), BD-Combo (Optional)
Graphics (Optional)	Intel GMA 4500 (Internal) ATI M96-M (ATI Mobility Radeon HD4650) (External) ATI M92-LP (ATI Mobility Radeon HD4330) (External)
Sound Chipset	ALC272-GR
Network (Optional)	Modem: V.92 modem (Optional) Wired LAN: Gigabit LAN Wireless LAN: 802.11ABGN / 802.11BGN / 802.11BG (Optional) Bluetooth: 2.0/2.1+EDR (Optional)
Express Card Slot (Optional)	Express Card (54mm)
Multi Card Slot	SD Card / SDHC Card / MMC
Ports (Optional)	USB 2.0 Port x 3, eSATA/USB Common Port, HDMI Port, Video (Monitor) Port, Microphone Jack, Headphone Jack, Wired LAN Port, Power IN Jack, Kensington Lock, Modem Port (Optional)
Dimensions	411.4 x 272.8 x 32.6~39.6mm
LCD	17.3" HD+ (1600x900, 1680x945), FHD (1920x1080) (Optional)
Battery (Optional)	Lithium-Ion Smart Battery: 6Cell or 12Cell (Optional)
Operating Environment	Temperature : -5~40°C for storage, 10~35°C when operating Humidity : 5~90% for storage, 20~80% when operating
Operating Voltage	100 - 240VAC
Frequency	50/60Hz
Output Power (Optional)	60W or 90W (Optional)
Output Voltage (Optional)	19V 3.16A (60W) or 19V 4.74A (90W) (Optional)



- The weight and dimension listed are approximate values and may vary a bit from the actual product.
- Optional components may not be provided or different components may be provided depending on the computer model.
- The system specifications are subject to change without notice.
- The hard disk drive capacity of a computer in which Samsung Recovery Solution is installed, is represented as smaller than
  the product specification.

## Wireless LAN Specifications (802.11a/b/g, 802.11n Card)

### Intel 802.11ABG WLAN

• The Name of the Registered Equipment: Special Low Power Wireless Device for Wireless Data Communication Systems.

ltem		Detailed Specifications		
	Dimensions	30.0 × 50.95mm (Width X Height)		
Physical Specifications	Operating Temperature And	Same as System Operations		
	Humidity	Temperature: Bet. 0°C and 70°C, Humidity: Less than 85%		
Power Specifications	Power	3.3V		
	Compatibility	IEEE 802.11a, IEEE 802.11b, IEEE 802.11g		
Network	Operating System	Microsoft Windows XP/Vista		
Specifications	Media Access Protocol (MAC)	CSMA/CA (Collision Avoidance) with Acknowledgement (ACK)		
	Security	Wired Equivalent Privacy support (WEP) 64bit/128bit WPA*		

<sup>\*</sup> This device supports the Wireless LAN Security Specifications WPA (Wi-Fi Protected Access) for Wi-Fi.

To connect to a WPA wireless network, you have to configure the settings according to the network connection environment. For detailed setting information, ask your network administrator.

## • Radio Specifications

RF Band	2.4GHz, 5GHz		
Supported Channels	Channels allowed per country.		
Device	Transceiver		
Standard Output Power	MAX 10mW		
	11a mode : OFDM		
Modulation Scheme	11b mode : DSSS		
	11g mode : OFDM		
	11a mode** : MAX 54Mbps		
Data Rate (Mbps)*	11b mode : MAX 11Mbps		
	11g mode*** : MAX 54Mbps		
Antenna Type	Built-in Antenna		

<sup>\*</sup> The data rate may differ from the real data transmission rate.

<sup>\*\* 11</sup>a mode is only supported when the device is connected to an IEEE 802.11a device. (e.g. Access Point supporting IEEE 802.11a)

<sup>\*\*\* 11</sup>g mode is only supported when the device is connected to an IEEE 802.11g device. (e.g. Access Point supporting IEEE 802.11g)

### Intel 802.11AGN WLAN

• The Name of the Registered Equipment : Special Low Power Wireless Device for Wireless Data Communication Systems.

Item		Detailed Specifications		
	Dimensions	30.0 × 50.95mm (Width X Height)		
Physical Specifications	Operating Temperature And Humidity	Temperature: Between 0°C and 70°C, Maximum Humidity: 85%		
Power Specifications	Power	3.3V		
	Compatibility	IEEE 802.11a, IEEE 802.11b, IEEE 802.11g, IEEE 802.11n		
Network	Operating System	Microsoft Windows XP/Vista		
Specifications	Media Access Protocol (MAC)	CSMA/CA (Collision Avoidance) with Acknowledgement (ACK)		
	Security	Wired Equivalent Privacy support (WEP) 64bit/128bit WPA*		

<sup>\*</sup> This device supports the Wireless LAN Security Specifications WPA (Wi-Fi Protected Access) for Wi-Fi.

To connect to a WPA wireless network, you have to configure the settings according to the network connection environment. For detailed setting information, ask your network administrator.

### Radio Specifications

RF Band	2.4GHz, 5GHz		
Supported Channels	Channels allowed per country.		
Device	Transceiver		
Standard Output Power	MAX 10mW		
Modulation Scheme	11a mode : OFDM 11b mode : DSSS 11g mode : OFDM 11n mode : MIMO		
Data Rate (Mbps)*	11a mode** : MAX 54Mbps 11b mode : MAX 11Mbps 11g mode*** : MAX 54Mbps 11n mode***: MAX 450Mbps, MAX 300Mbps		
Antenna Type	Built-in Antenna		

<sup>\*</sup> The data rate may differ from the real data transmission rate.

<sup>\*\* 11</sup>a mode is only supported when it is connected to an IEEE802.11a device (e.g. Access Point supporting IEEE802.11a).

<sup>\*\*\* 11</sup>g mode is supported only when you are connected to an IEEE 802.11g device (e.g. An Access Point supporting IEEE 802.11g).

<sup>\*\*\*\*11</sup>n mode is only supported when it is connected to an IEEE802.11n device (e.g. Access Point supporting IEEE802.11n). The data rate in 11n mode is determined by the number of antenna and Access Point type.

## Wireless LAN Specifications (802.11BG Card)

### Intel 802.11BG WLAN

• The Name of the Registered Equipment: Special Low Power Wireless Device for Wireless Data Communication Systems.

Item		Detailed Specifications		
	Dimensions	30.0 × 50.95mm (Width X Height)		
Physical Specifications	Operating	Same as System Operations		
	Temperature And Humidity	Temperature: Bet. 0°C and 70°C, Humidity: Less than 85%		
Power Specifications	Power	3.3V		
	Compatibility	IEEE 802.11b, IEEE 802.11g		
Network	Operating System	ating System Microsoft Windows XP/Vista		
Specifications	Media Access Protocol (MAC)	CSMA/CA (Collision Avoidance) with Acknowledgement (ACK)		
	Security	Wired Equivalent Privacy support (WEP) 64bit/128bit WPA*		

<sup>\*</sup> This device supports the Wireless LAN Security Specifications WPA (Wi-Fi Protected Access) for Wi-Fi.
To connect to a WPA wireless network, you have to configure the settings according to the network connection environment. For detailed setting information, ask your network administrator.

## • Radio Specifications

RF Band	2.4GHz		
Supported Channels	Channels allowed per country.		
Device	Transceiver		
Standard Output Power	ord Output Power MAX 10mW		
W. I. I. C. C. I	11b mode : DSSS		
Modulation Scheme	11g mode : OFDM		
Data Poto (Mhno)*	11b mode : MAX 11Mbps		
Data Rate (Mbps)*	11g mode** : MAX 54Mbps		
Antenna Type	Built-in Antenna		

<sup>\*</sup> The data rate may differ from the real data transmission rate.

<sup>\*\* 11</sup>g mode is only supported when the device is connected to an IEEE 802.11g device. (e.g. Access Point supporting IEEE 802.11g)

### Realtek 802.11BGN WLAN

• Device Name for Formal Registration : Low Power Wireless Device for Wireless Data Communication Systems.

Туре		Detailed Specifications		
	Dimensions	30 x 26.65 mm (Width X Height)		
Physical Specifications	Operating Temperature And Humidity	Temperature: Bet. 0°C and 70°C, Humidity: Less than 85%		
Power Specifications	Power	3.3V		
	Compatibility	IEEE 802.11b, IEEE 802.11g, IEEE 802.11n		
Network	Operating System	Microsoft Windows XP/Vista		
Specifications	Media Access Protocol (MAC)	CSMA/CA (Collision Avoidance) with Acknowledgement (ACK)		
	Security	Wired Equivalent Privacy support (WEP) 64bit/128bit WPA*		

<sup>\*</sup> This device supports the Wi-Fi wireless LAN security specifications, WPA (Wi-Fi Protected Access).

To connect to a network constructed with a WPA, the appropriate settings for the network are required.

For detailed settings, ask your network administrator.

### Radio Specifications

RF Band	2.4GHz		
Supported Channels	The channels allowed for the country.		
Device	Transceiver		
Standard Output Power	MAX 10mW		
	11b mode : DSSS		
Modulation Scheme	11g mode : OFDM		
	11n mode: MIMO		
	11b mode : MAX 11Mbps		
Data Rate (Mbps)*	11g mode** : MAX 54Mbps		
	11g mode*** : Max. 300 Mbps		
Antenna Type	Built-in Antenna		

<sup>\*</sup> The data rate may differ from the actual data rate.

<sup>\*\* 11</sup>g mode is only supported when this device is connected with an IEEE802.11g device (E.g. An Access Point that supports IEEE802.11g).

<sup>\*\*\* 11</sup>n mode is only supported when this device is connected with an IEEE802.11n device (E.g. An Access Point that supports IEEE802.11n).

### Atheros 802.11BG WLAN

• The Name of the Registered Equipment: Special Low Power Wireless Device for Wireless Data Communication Systems.

Item		Detailed Specifications		
	Dimensions	30.0 × 50.95mm (Width X Height)		
Physical Specifications	Operating Temperature And Humidity	Temperature: Between 0°C and 70°C, Maximum Humidity: 85%		
Power Specifications	Power	3.3V		
	Compatibility	IEEE 802.11b, IEEE 802.11g		
Network	Operating System	Microsoft Windows XP/Vista		
Specifications	Media Access Protocol (MAC)	CSMA/CA (Collision Avoidance) with Acknowledgement (ACK)		
	Security	Wired Equivalent Privacy support (WEP) 64bit/128bit WPA*		

<sup>\*</sup> This device supports the Wireless LAN Security Specifications WPA (Wi-Fi Protected Access) for Wi-Fi.

To connect to a WPA wireless network, you have to configure the settings according to the network connection environment. For detailed setting information, ask your network administrator.

## • Radio Specifications

RF Band	2.4GHz		
Supported Channels	Channels allowed per country.		
Device	Transceiver		
Standard Output Power	Power MAX 10mW		
	11b mode : DSSS		
Modulation Scheme	11g mode : OFDM		
Data Data (Mhma\*	11b mode : MAX 11Mbps		
Data Rate (Mbps)*	11g mode** : MAX 54Mbps		
Antenna Type	Built-in Antenna		

<sup>\*</sup> The data rate may differ from the real data transmission rate.

<sup>\*\* 11</sup>g mode is supported only when you are connected to an IEEE 802.11g device (e.g. An Access Point supporting IEEE 802.11g).

## **Registered Trademarks**

Samsung is a registered trademark of Samsung Co., Ltd. SENS is a registered trademark of Samsung Electronics Co., Ltd.

Intel, Pentium/Celeron are registered trademarks of the Intel Corporation.

Microsoft, MS-DOS, and Windows are registered trademarks of the Microsoft Corporation.

SISO Trusurround XT is a trademark of SRS Labs, Inc.

TruSurround XT technology is incorporated under license from SRS Labs, Inc.

SRS TruSurround XT™ processes multichannel audio content to create a truly immersive surround sound experience with rich bass and clear dialog from the laptop speakers or headphones.

is a trademark of SRS Labs, Inc.

WOW HD technology is incorporated under license from SRS Labs, Inc.

SRS WOW HD™ significantly improves the playback quality of mono and stereo audio, delivering a dynamic 3D entertainment experience with deep bass and high frequency clarity for crisp detail.

SISO is a trademark of SRS Labs, Inc.

CS Headphone technology is incorporated under license from SRS Labs, Inc.

CS Headphone™ delivers a 5.1 surround sound experience over standard headphones or earbuds when listening to multichannel content, such as DVD movies.

All other product or company names mentioned herein are registered trademarks of their respective companies.

#### **ENERGY STAR® Partner**



As an ENERGY STAR® Partner, SAMSUNG has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.

# Glossary

The Glossary lists the terminologies used in this User Guide. For terminologies other than these, look in Windows Help.

### **Backup**

A way to save the current data to restore it later if necessary. A backup is a way to restore computer data when the data or computer is damaged.

#### Client

This refers to a computer that uses a shared network resource provided by a server.

**DDR SDRAM** (Double Data Rate Synchronous Dynamic Random Access Memory)

DRAM is a memory type whose cells consist of a capacitor and transistor manufactured at a low price. SDRAM is a memory type whose performance has been improved by synchronizing the clock with the external CPU clock. DDR SDRAM is a memory type whose performance has been improved by doubling the operating speed of the SDRAM and is widely used nowadays. This computer uses DDR SDRAM.

### **Device Manager**

An administrative tool used to manage computer devices. You can add or remove hardware or update a device driver using the Device Manager.

#### Direct X

An application interface developed to enable Windows application programs to access hardware devices at a very high speed. Since the operating speed of graphics, memory and sound cards must be very fast to provide high quality video and sound for games, Direct X enables faster control and interaction between applications and hardware devices. By using Direct X, the multimedia performance of Windows has been hugely improved.

#### Driver

Software that interacts between the hardware and the operating system. An operating system knows the hardware information and controls the hardware. In general, a driver is supplied with the corresponding hardware device.

### **DVD** (Digital Versatile Disk)

DVD was developed to replace CD (compact disk). Although the shape and size of the disc are the same as that of a CD, the capacity of a DVD is at least 4.7GB while the capacity of a CD is 600MB. DVD video is digital unlike VHS (analog) video and supports MPEG2 compression and digital audio. To play a DVD, a DVD drive is required.

#### **Firewall**

A security system used to protect an internal network or intranet from external networks through an authentication procedure.

### **Hibernation Mode**

A power mode that saves all data in memory to the hard disk and turns the CPU and hard disk off. When canceling Hibernation Mode, all application programs that were running are restored to their last state.

#### Icon

This refers to a small image that represents a file that users can use.

### LAN (Local Area Network)

A communications network connecting computers, printers and other devices within a local area such as within a building. A LAN enables all connected devices to interact with other devices on the network. The current LAN uses the Ethernet media access control method developed in the early 1980s. To connect to an Ethernet, a network card called a LAN card, Ethernet card or network interface card is required. To exchange data between computers, a protocol is required besides the hardware equipment. Windows Vista uses TCP/IP as the default protocol.

### **LCD** (Liquid Crystal Display)

There are Passive Matrix and Active Matrix LCD types. This computer uses the Active Matrix type LCD called a TFT LCD. Since an LCD is implemented by transistors instead of a cathode-ray tube unlike a CRT, its size can be slim. And because it does not blink, it reduces eye strain.

#### Network

A group of computers and devices, such as printers and scanners, connected by a communications link. A network can be either small or large and can be connected permanently through cables or temporarily through telephone lines or wireless links. The biggest network is the Internet, a worldwide network.

#### **Network Administrator**

A user who plans, configures and manages network operations. Sometimes, a network administrator is called a system administrator.

#### **Notification Area**

This refers to the right area of the Taskbar including program icons such as the volume control, the power options and the time.

#### **Power Schemes**

This refers to a pre-determined power management option group. For example, you can set the time the computer waits before entering Standby Mode, or before the monitor or hard drive turns off. The settings are saved as a power scheme.

### **Quick Launch**

This refers to a toolbar that can be configured so that you can launch a program such as Internet Explorer or display the Windows Desktop with one click. You can add any icon to the quick launch area of the Taskbar and launch frequently used program by clicking that icon.

#### Server

In general, a server refers to a computer that provides shared resources for network users.

#### Share

This refers to setting a resource of a computer such as a folder or printer so that other users can also use it.

#### **Shared Folder**

A folder that can be used by other users on the network.

### Sleep Mode

A power mode that enables computers to save power consumption when they are not being used. When a computer is in Sleep Mode, the data on the computer memory is not saved to the hard disk. If the power is turned off, the data in memory will be lost.

### System File

System Files refer to files that are read and used by the Windows operating system. In general, system files must not be deleted or moved.

### **USB** (Universal Serial Bus)

This refers to a serial interface standard developed to replace the conventional interface standards such as Serial and PS/2. While USB 1.1 supports 12Mbps (12 million bits per second), USB 2.0 supports a data rate that is 40 times (480Mpbs) faster than that of USB 1.1. The data rate of USB 2.0 is equivalent to that of IEEE1394. Therefore USB 2.0 is used for A/V devices supported by IEEE 1394 and a 2nd HDD and CDRW that require a high data rate.

### Windows Media Player

A multimedia program included with Windows. Using this program, you can play a media file, create an audio CD, listen to a radio broadcast, search and manage media files, and copy files to a portable device, etc.

# Index

В		L		S	
Battery	134	LCD Brightness	124	Safety Precautions	8
Battery Calibration	140			Samsung Update Plus	117
BIOS Setup	125	M		Security Lock Port	141
Bluetooth	108		132	Shortcut Keys	51
Booting Priority	131	Memory  Modem Connection	107	Status Indicators	43
		Multi Card Slot	58		
С		Multimedia	115	Т	
CD Drive / Recording	56			Touchpad	53
Charge	135	N			
Click	54	Network	103	U	
Connect / Output Monitor	62		103		87
Connecting AP / AP	101	Network Status Diagnosis	106	User Accounts / Switch User	01
Control Panel	85				
		P		V	
D		Password	129	Volume Control	70
Desktop / Change	75	Product Name	42		
Dual View	68	Product Specifications	186	W	
Dadi view	00	Program	114	Windows Vista	73
E				Wired Network	98
		R		Wireless Network	101
Easy Battery Manager	137	Recorder	70		
Easy Network Manager	103	Remaining Battery Charge	136		
ExpressCard Slot	61	Resolution / Color	89		
Н					
Help	74				